PROPERTY OF DEPT. C-270
METROLOGY LAB.
DO NOT REMOVE
FROM AREA

Operating and Service Manual

GOULD

PROPERTY OF DEPT. C-270
METROLOGY LAB.
DO NOT REMOVE
FROM AREA

GOULD BRUSH

MANUAL NO.
110-8043XX

GOULD 110

STRIP CHART RECORDER

15-4318-00, 15-4328-00

with

Multi-Span DC Preamplifier	13-4715-06
Fixed-Span DC Preamplifier	13-4715-07
Input Signal Coupler	13-4715-08

PRINTED FEB, 1976
COPYRIGHT 1976

Gould Inc., Instrument Systems Division
3631 Perkins Avenue-Cleveland, Ohio 44114

1ST PRINTING
PRINTED IN U.S.A.

Digitized by the Internet Archive
in 2026

https://archive.org/details/manualsplus_11761

GOULD 110 STRIP CHART
MANUAL REVISIONS
to 1st Printing

In keeping with the theme of constant improvement, the Gould Documentation Department, in an effort to maintain current manuals, has included manual Revisions. These revisions should be manually inserted in ink, on the appropriate pages.

PAGE	DESCRIPTION
8.2	Change item 3 part number from 10-286044-303 to 287162. Ref: DCN 19939.
	Change item 13 part number and description from 25-106766-4; Nut, Hex to 285653-2; Knob, Control. Ref: DCN 19939.
	Change item 14 part number from 285651-3 to 285651-1. Ref: DCN 19939.
	Add item 15; 281502-1; Contact, Elec. Ref: DCN 20497.
8.15	Delete item C102; 240352-102; Capacitor. Ref: DCN 20343. (schematic is correct)
8.16	Change item R117 part number from 284878-103 to 284878-503. Ref: DCN 20343.
	Change item R122 part number from 5-241111-104 to 5-241111-102. Ref: DCN 20343.
	Delete item R141; 5-115557-3R9; Resistor. Ref: DCN 20486.
	Add item S103; 286423; Switch. Insert immediately under item R142.
8.17	Delete item C-102. Ref: DCN 20343.
	Change the designation "R-141" to "JUMPER". Ref: DCN 20486.

PAGE	DESCRIPTION
2.4	Figure 2-5: Delete "COMMON MODE VOLTAGE" with its arrows and dimension line on left side. Figure 2-6: Change note "INSTALL GROUND AT SIGNAL SOURCE" to "OPTIONAL GROUND AT SIGNAL SOURCE".
7.3	Figure 7-1 Change circled item numbers as follows:

ITEM NO.	REVISION
1	Delete
2	Delete
3	Change to "R101 5k, 4W"
4	Change to "CR101 & 102"
5	Change to "H"
6	Change to "G"
7	Change to "F"
8	Change to "E"
9	Change to "D"
10	Change to "C"
11	Change to "B"
12	Change to "A"
13	Change to "REAR INPUT TERMINALS"
14	Delete
15	Change to "R104 BALANCE POT"
16	Change to "R203 5K, 4W"
17	Delete
18	Change to "Front input Terminals"

7.4 Change sentence 7.4.2a to read "Short the three input terminals (HI, LO, and GD) to the preamplifier together.

Change sentence 7.4.2d to read "Connect a differential voltmeter to the output of the preamplifier (positive lead to pin D and negative lead to pin G). See Figure 7-2."

Change the first line of 7.4.2.h to read "Rotate fine balance adjust (R107) counter-clockwise"

7.5 Figure 7-2 change circled item numbers as follows:

ITEM NO.	REVISION
1	Delete
2	Change to "H"
3	Change to "G F"
4	Change to "E"
5	Change to "D"
6	Change to "C"
7	Change to "B"
8	Change to "A"
9	Change to "REAR INPUT TERMINALS"
10	Change to "R135 OFFSET ADJUST"
11	Change to "R108 COURSE BALANCE"
12	Delete
13	Change to "FRONT INPUT TERMINALS"
14	Change to "OFFSET"

PAGE	DESCRIPTION	
7.5 (Continued)	ITEM NO.	REVISION
	15	Change to "RESPONSE"
	16	Change to "R107 FINE BALANCE POT"
	17	Change to "SPAN"

8.2

Add to item 6 description "(All 115 volt models)"

Add second part no. & description to item 6 as follows: "266924-7; Fuse (All 230 volt models)". Insert immediately under present item 6 part no.& description.

Change item 7 description from "Pulley-Zot." to "Pulley-20 T. (All 60 Hz models)"

Add second part no.& description to item 7 as follows: "1-282930-3; Pulley - 24 T. (All 50 Hz models)". Insert immediately under present item 7 part no. and description.

8.18

Add the following model nos. to the tab listing.

15-4618-16	15-4628-16
15-4618-10	15-4628-10
15-4618-06	15-4628-06
15-4618-00	15-4628-00

Change Note next to J201-1:

From: Strip Chart Recorder, Single Channel, 15-4318-00
To: Strip Chart Recorder, Single Channel,

Change Note next to J201-2:

From: Optional 2nd Channel, on Model 15-4328-00 only.
To: Optional 2nd Channel

Reference: DCN 21673
Change Revision Level to C-2.

TABLE OF CONTENTS

SECTION		TITLE	PAGE
I		GENERAL INFORMATION	
	1.1	SCOPE	1.1
	1.2	DESCRIPTION	1.1
	1.3	RECORDER SPECIFICATIONS	1.4
	1.3.1	General	1.4
	1.3.2	Chart Transport	1.4
	1.3.3	Electrical	1.5
	1.3.4	Environmental	1.6
	1.3.5	Integrator	1.6
	1.4	PREAMPLIFIER SPECIFICATIONS	1.7
	1.4.1	Input Coupler	1.7
	1.4.2	Fixed Span DC	1.7
	1.4.3	Multi-Span DC	1.9
	1.5	MODELS	1.10
	1.6	OPTIONS	1.11
	1.7	ACCESSORIES	1.11
	1.8	SUPPLIES	1.12
II		INSTALLATION	
	2.1	GENERAL	2.1
	2.2	SERVICE UPON RECEIPT	2.1
	2.3	PREAMPLIFIERS	2.1
	2.3.1	Input Signal Coupler	2.1
	2.3.2	Fixed Span and Gain Module(s)	2.1
	2.3.3	Multi-Span	2.1
	2.4	ELECTRICAL CONNECTIONS	2.1
	2.4.1	Signal Connections	2.1
	2.4.2	AC Power Input	2.2
	2.4.3	Remote Chart Drive Control	2.2
	2.4.4	External Chart Drive	2.2
	2.4.5	Options	2.2
III		OPERATION	
	3.1	GENERAL	3.1
	3.2	FRONT PANEL CONTROLS AND INDICATORS	3.1
	3.3	REAR PANEL CONNECTIONS	3.4
	3.4	WRITING TABLE	3.4
	3.5	PEN HEAT CONTROL	3.4
	3.6	SET UP AND OPERATION	3.4
	3.6.1	General	3.4
	3.7	INTEGRATOR OPERATION	3.6
IV		THEORY OF OPERATION	
	4.1	GENERAL	4.1
	4.2	RECORDER CONTROL ASSEMBLY	4.1
	4.2.1	General	4.1
	4.2.2	AC Distribution	4.2
	4.2.3	End of Chart Circuitry	4.4
	4.2.4	Stepper Motor Circuitry	4.4
	4.2.5	115/230 Volt Switching	4.4
	4.2.6	External Chart Drive Pulse	4.4
	4.2.7	Event Marker Control	4.4
	4.2.8	Power Supply	4.4

SECTION		TITLE	PAGE
IV		THEORY OF OPERATION (Cont'd)	
	4.3	DRIVE AMPLIFIER	4.5
	4.4	INTEGRATOR	4.7
	4.5	LIMIT SWITCH	4.9
	4.5.1	General Description	4.9
	4.5.2	Circuit Description	4.9
	4.6	INPUT SIGNAL COUPLER	4.9
	4.6.1	General Description	4.9
	4.6.2	Circuit Description	4.9
	4.6.3	Front Panel OFFSET Control	4.9
	4.6.4	Front Panel TRIM Control	4.9
	4.7	FIXED SPAN PREAMPLIFIER	4.9
	4.7.1	General Description	4.9
	4.7.2	Circuit Description	4.11
	4.8	MULTI SPAN PREAMPLIFIER	4.12
	4.8.1	General Description	4.12
	4.8.2	Circuit Description	4.13
V		TROUBLESHOOTING	
	5.1	GENERAL	5.1
	5.2	TROUBLESHOOTING GUIDE	5.1
VI		MAINTENANCE	
	6.1	GENERAL	6.1
	6.2	COVER ASSEMBLY	6.1
	6.2.1	Removal	6.1
	6.2.2	Installation	6.1
	6.3	CHART PAPER INSTALLATION	6.1
VII		CALIBRATION	
	7.1	GENERAL	7.1
	7.1.1	Test Equipment Required	7.1
	7.1.2	Preliminary Setup	7.1
	7.2	INPUT SIGNAL COUPLER (13-4715-08)	7.1
	7.2.1	Calibration Checkout	7.1
	7.2.2	Offset Operation Checkout	7.2
	7.2.3	Full Scale Span Calibration	7.2
	7.3	FIXED SPAN PREAMPLIFIER (13-4715-07)	7.2
	7.3.1	Preamplifier Balance	7.2
	7.3.2	Gain Accuracy	7.2
	7.3.3	Response Check	7.3
	7.3.4	Maximum Safe Input	7.3
	7.3.5	Common Mode Rejection	7.3
	7.3.6	Noise Check	7.4
	7.4	MULTI SPAN PREAMPLIFIER (13-4715-06)	7.4
	7.4.1	System Calibartion	7.4
	7.4.2	Chopper Amplifier Balance	7.4
	7.4.3	Offset Potentiometer	7.4
	7.4.4	Response Check	7.6
	7.4.5	Noise Check	7.6

SECTION	TITLE	PAGE
VII	CALIBRATION (Cont'd)	
7.4.6	Balance Check	7.6
7.4.7	System Gain Check	7.6
7.5	DRIVE AMPLIFIER (886046)	7.7
7.5.1	Preliminary Setup	7.7
7.5.2	Reference Supply	7.7
7.5.3	Limiter Position and Span Adjustment	7.7
7.5.4	Pen Position	7.7
7.5.5	Span	7.7
7.5.6	Damping	7.9
7.5.7	End of Chart Sensor	7.9
7.5.8	Pen Heat	7.9
7.5.9	Chart Speed Check	7.9
7.5.10	Writing Quality	7.11
7.5.11	External Pulse Drive Test	7.11
7.6	LIMIT SWITCH	7.11
7.7	CHART INTEGRATOR	7.12
7.7.1	Initial Set-Up	7.12
7.7.2	Polarity Sense Offset Adjust	7.12
7.7.3	Full Scale Time Adjustment	7.12
7.7.4	Balance Adjust (Upscale and Downscale)	7.13
7.7.5	Pen Centering and Span Adjustment	7.13
7.7.6	Damping Adjustment	7.13
7.7.7	Final Balance Adjustment	7.13
7.7.8	Baseline Zero Check	7.13
7.7.9	Accuracy Check	7.14
7.7.10	Mechanical - Electrical Check	7.14
7.7.11	Overrange Check	7.14
VIII	PARTS IDENTIFICATION	
8.1	GENERAL	8.1
8.2	MAINFRAME (15-4318-00, 15-4328-00)	8.1
8.3	PREAMPLIFIERS	8.1
8.4	OPTIONS/ACCESSORIES	8.1

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
1-1	Gould 110 Strip Chart Recorder	1.1
1-2	Input Signal Coupler (13-4715-08)	1.2
1-3	Fixed Span DC Preamplifier (13-4715-07)	1.3
1-4	Multi Span DC Preamplifier (13-4715-06)	1.3
2-1	Shipping List & Installation Instructions (Rack Mounted Models)	2.3
2-2	Shipping List & Installation Instructions For Lockable Door (Rack Mounted Models)	2.3a
2-3	High Level, Grounded, Signal Source	2.4
2-4	Millivolt Level, Grounded, Signal Source	2.4
2-5	High Level, Floating, Signal Source	2.5
2-6	Millivolt Level, Floating, Signal Source	2.5
2-7	Left Margin Event Marker (11-6222-16)	2.6
2-8	Right Margin Event Marker (11-6222-17)	2.7
3-1	Front Panel Controls and Indicators	3.3
3-2	Rear Panel Connections	3.5
4-1	Recorder Block Diagram	4.1
4-2	Recorder Control Assembly Block Diagram	4.2
4-3	Recorder Theory of Operation Diagram	4.3
4-4	Drive Amplifier Theory of Operation Diagram	4.6
4-5	Integrator Display Area	4.7
4-6	Fixed Span Preamplifier Block Diagram	4.10
4-7	Fixed Span Theory of Operation Diagram	4.11
4-8	Multi Span Preamplifier Block Diagram	4.12
4-9	Multi Span Theory of Operation Diagram	4.14
4-10	Gain Formula	4.14
6-1	Writing Table Removal	6.2
6-2	Writing Table Assembly	6.2
6-3	Grooves in Paper Supply Core	6.3
6-4	Installation Diagram	6.3
6-5	Internal Take-Up	6.3
7-1	Fixed Span Preamplifier (13-4715-07)	7.3
7-2	Multi Span Preamplifier (13-4715-06)	7.5
7-3	Drive Amplifier (886046)	7.8
7-4	Recorder Control Assembly	7.10
7-5	Limit Switch Indicators	7.11
7-6	Chart Integrator	7.14

FIGURE	TITLE	PAGE
8-1	Recorder Assembly (15-4318-00, 15-4328-00)	8-3
8-2	Recorder Subassembly-Single and Dual Channel (885287-1,-2)	8.5
8-3	Chassis Assy-Single and Dual Channel (885111-1, -2)	8.8
8-4	Pen Drive Assy (885112)	8.10
8-5	Table Assy (884885)	8.12
8-6	Recorder Control Assy (885088)	8.13
8-7	Case Assy (886139)	8.14
8-8	Recorder Control Board Assy (886394)	8.17
8-9	Recorder Control Schematic (286363)	8.18
8-10	Drive Amplifier Board Assy (886046)	8.22
8-11	Drive Amplifier Schematic (286364)	8.24
8-12	Input Signal Coupler (13-4715-08)	8.25
8-13	Input Signal Coupler Board Assy (787585)	8.26
8-14	Input Signal Coupler Schematic (287302)	8.27
8-15	Fixed Span DC Amplifier (13-4715-07)	8.28
8-16	Fixed Span Amplifier Board Assy (886021)	8.29
8-17	Fixed Span Amplifier Schematic (286362)	8.30
8-18	Multi Span Amplifier Assy (13-4715-06)	8-31
8-19	Multi Span Amplifier Board Assy (885981)	8.34
8-20	Multi Span Amplifier Schematic (286361)	8.36
8-21	Limit Switch Assy-Single and Dual Channel (11-6103-01, -02)	8.38
8-22	Limit Switch Board Assy-Single Channel (886705) Dual Channel (886707)	8.42
8-23	Limit Switch Schematic (286368)	8.44
8-24	Integrator Pen-Single and Dual Channel (11-6105-00, -01)	8.47
8-25	Integrator Board Assy (886663)	8-50
8-26	Integrator Power Supply Board Assy (786661)	8-52
8-27	Integrator Pen Schematic (286366)	8-53
8-28	Retransmitting Potentiometer Assy-Single Channel (11-6102-01)	8.54
8-29	Retransmitting Potentiometer Assy-Dual Channel (11-6102-02)	8.55

LIST OF TABLES

TABLE	TITLE	PAGE
1-1	Gould 110 Strip Chart Recorder Models	1.10
1-2	Gould 110 Options	1.11
1-3	Accessories	1.11
1-4	Strip Chart Recorder Supplies	1.12
4-1	Power Supply Pin Connections	4.5
4-2	Fixed Span Gain Modules	4.10

SECTION I

GENERAL INFORMATION

1.1 SCOPE

This manual describes the Gould 110 strip chart recorder (Figure 1-1) and provides instructions for installation, operation, troubleshooting, and maintenance procedures. Theory of operation, and calibration procedures are also furnished. An illustrated parts breakdown is located in the rear of the manual.

1.2 DESCRIPTION

The Gould 110 is a ten inch multi-speed strip chart recorder that is available in single or dual channel models. A series of plug-in signal conditioning modules and accessories are available to tailor the recorder to a specific application.

The model 110 utilizes a thermal writing technique with ceramic tip pens and dual heat controls that produce permanent blue traces on special paper which does not smudge from pressure or handling.

This thermal writing technique is superior to the conventional capillary ink writing method. Pen clogging and pen tip dry-out is eliminated. This writing technique also provides electrically adjustable trace density, superior writing system reliability, and permits operation in any position.

The recorder utilizes sprocket driven NCR thermal chart paper with a 9.75 inch wide grid. A full 120-foot roll of paper is easily loaded in the removable writing table assembly. For maximum convenience of viewing, the table may be positioned at any of three angles.

Ten chart speeds from one inch/hour to eight inches/minute are switch selectable, and the chart drive can be started and stopped from either front panel or remote controls. The external pulse input is TTL compatible and permits the chart to be pulse driven and synchronized for operation with external devices. An external pulse input from 0 to 240 pulses/sec. will provide chart speeds from 0 to 16 inches/minute.



bi 1821

FIGURE 1-1 GOULD 110 STRIP CHART RECORDER

Fixed and multi-span preamplifiers are available with the strip chart recorder. Plug-in signal conditioners are available with a selection of different input voltages. Signal conditioners plug into the front panel and are powered by the drive amplifier power supply located in the recorder. High accuracy at low signal levels is achieved by the use of a chopper stabilized amplifier which corrects for errors caused by the input offset voltage and current drifts. The following preamplifiers may be ordered with the recorder.

- Input Signal Coupler 13-4715-08 (Figure 1-2) - Provides pen positioning, internal calibration, and seven full-scale ranges of, 1, 2, 5, 10, 20, 50, and 100 volts from low impedance sources.
- Fixed Span DC Preamplifier 13-4715-07 (Figure 1-3) - Precision signal conditioner, utilizing a chopper amplifier with pen positioning and a choice of 16 plug-in fixed gain printed circuit cards which provide full-scale ranges from 1 millivolt to 100 volts.
- Multi-Span DC Preamplifier 13-4715-06 (Figure 1-4) - Chopper amplifier signal conditioner with 18 switch selectable, full-scale ranges from 100 microvolts to 100 volts, in addition to calibrated zero offset and switch selectable output filtering.

An optional electronic chart integrator (11-6105-00, 01) is available. It records the area under the curve of the analog input signal using a separate servo driven pen. This display occupies a one inch wide chart strip located to the right of the analog channel display.



bi 1822

FIGURE 1-2 INPUT SIGNAL COUPLER (13-4715-08)



FIGURE 1-3 FIXED SPAN DC PREAMPLIFIER (13-4715-07)



FIGURE 1-4 MULTI SPAN DC PREAMPLIFIER (13-4715-06)

1.3 RECORDER SPECIFICATIONS

1.3.1 General

	Portable	Rack Mounted
Overall Size	Height: 7.8 in. (19.8 cm) Width: 19 in. (48.3 cm) Depth: 14.1 in. (35.8 cm)	7 in. (17.8 cm) 19 in. (48.3 cm) 14.1 in. (35.8 cm)

Weight
- Single Channel ..... 28 lbs. (12.5 kg.)
- Dual Channel ..... 33 lbs. (15.0 kg.)

Channels
- Analog ..... One standard (second full width channel optional)
- Integrator ..... One optional (sharing same time line with analog channel number one)

Event Marker ..... Located on left and right margins (optional)

Writing Method ..... Hot tip thermal pen

Trace Presentation ..... Rectilinear

Trace Width ..... Adjustable pen heat with front panel control

Signal Limiters ..... Built-in adjustable electronic

Writing Table ..... Vertical (may be tilted to writing positions of 15° and 30° off vertical or removed)

1.3.2 Chart Transport

Speed
- English ..... 1,2,3,6,12,30, and 60 in/hr. (2,4, and 8 in/min.)
- Metric ..... 2.5, 5, 7.5, 15, 30, 75 and 150 cm/hr. (5, 10, and 20 cm/min.)

Chart Speed Accuracy ..... Sprocket drive, speed error non-cumulative at nominal line frequency.

Paper Wander ..... Less than ±0.1 division

Paper Interlock ..... Automatic sensing of chart paper; shuts down heat, servo, and chart drive when paper supply is exhausted.

Chart Paper
- Length ..... 120 ft. (roll with length of paper remaining printed on chart edge.)
- Width ..... 11 in.
- Roll Diameter ..... 2.5 in. (max.)

Paper Discharge ..... From bottom of transport or may be internally rewound.

Chart Paper Grid

All Models ..... Precision printed and registered grids. Event marker channels on left and right margins.

English (standard) ..... 9.75 in. analog channel width divided into 100 longitudinal (amplitude) lines with every fifth accentuated. 0.1 in. traverse (timing) lines with every fifth accentuated.

English (with integrator channel) ..... 7.7 in. analog channel width divided into 100 longitudinal divisions with every fifth accentuated, plus three additional longitudinal divisions on the right providing a total channel width of 103 divisions. 0.1 in. transverse lines with every fifth accentuated on both analog and integrator channels. 0.975 inch integrator channel divided into ten longitudinal divisions.

Metric ..... Same as "English Standard" except 2.0 mm transverse lines with every fifth accentuated.

Metric (with integrator channel) ..... Same as "English Standard with integrator channel" except 2.0 mm transverse lines on both analog and integrator channels with every fifth accentuated.

1.3.3 Electrical

Power Input ..... 115 vac, 60 Hz, 44 va (single channel)
115 vac, 60Hz, 69 va (dual channel)

Remote Start and Stop ..... Actuated by an external switch closure at preselected chart speed.

External Pulse Drive ..... TTL compatible input signal to a maximum of +30 volts.

Paper Travel

60Hz Unit ..... 900 pulses/in; 360 pulses/cm (Metric)
50Hz Unit ..... 750 pulses/in.; 300 pulses/cm (Metric)

Input Pulse Repetition Rate ..... 240 pulses/second (maximum) from external source.

Current Consumed by Options

Limit Switches ..... 21 ma (single channel) 41 ma (dual channel)
Chart Integrator ..... 17 ma
Fixed Gain Preamplifier ..... 1.7 ma
Multi Span Preamplifier ..... 1 ma
Event Marker ..... 200 ma (each)

Response Time ..... 0.25 sec. full scale (maximum)

Inaccuracy ..... ±0.15% of full scale (including non-linearity and deadband) at 25° c.

Non-Linearity ..... ±0.1% of full scale.

1.3.4 Environmental

Operating Temperature Range ..... 0° to +50° C (+32° F to +122° F)

Storage
- Without Chart Paper ..... -40° C to +85° C (-40° F to +185° F)
- With Chart Paper ..... -40° C to +70° C (-40° F to +158° F)

Vibration and Shock ..... Standard commercial practice

1.3.5 Integrator Specifications (Model 11-6105-00 and -01)

Integration Accuracy ..... ±0.25% of full scale count rate per minute under normal operating conditions.

Integrator Setability ..... ±2 counts per minute under normal operating conditions.

Full-Scale Count Rate ..... 6000 counts per minute.

Overrange Capability ..... 400% of full scale count rate to 24,000 counts per minute (maximum)

Integrator Channel Width ..... 0.975 inch to right of analog channel divided into ten divisions.

Threshold of Integration ..... Less than 10 millivolts. Referred to analog channel input.

Stability .....

	ZERO	GAIN
TIME	1 Count/Min. / 24 Hrs.	.01% / 24 Hrs.
TEMP.	1.5 Counts/Min. / C°	.075%/C°
LINE	0.05 Counts/Min. / %△	0.01 / %△

Polarity Indication ..... Blips occur on upscale peaks for positive integration and on the down scale peaks for negative integration. 600 or 1000 count blip interval selectable by switch on P.C. Board Assy.

Environmental ..... a) Operating 0-50° C.
b) Storage -40° C to 85° C.
c) Humidity: 80% @ 32° C. (W/O Condensation).

1.4 PREAMPLIFIER SPECIFICATIONS

1.4.1 Input Coupler 13-4715-08

Measurement Range ..... 1 volt full scale to 100 volts full scale, dependent on internal connection.

Sensitivity ..... 1,2,5,10,20,50, and 100 volts full scale (internally selectable)

Accuracy ..... ±.25% of full scale, settable using front panel trim control.

Input Circuit ..... Floating & Guarded.

Zero Offset ..... ±100% of Full scale.

Input Resistance ..... 10K ohms minimum (attenuator into 10K ohms of drive amplifier) 10K ohms/volt.

Maximum Allowable Input Voltage ..... 100 volts dc or peak ac as normal mode

Common Mode Rejection ..... Greater than 120 db at dc with 1000-ohm unbalance. Greater than 80dB at 60Hz with 1000-ohm unbalance.

Maximum off-Ground Voltage ..... 220 volts dc or peak ac.

Zero Line Instability (After 30-minute warm-up) ..... ±0.1% of full scale for 24 hours. ±0.1% of full scale per °C ±0.05% of full scale per 10% line change.

Gain Instability (After 30-minute warm-up) ..... ±0.01% of reading for 24 hours ±0.01% of reading per °C (on 100 volts full scale) ±0.01% of reading for 10% line change

Output Noise ..... ±0.1% of full scale

Operating Temperature ..... 0° C to 50° C (+32° F to +122° F)

Storage Temperature ..... -40° C to +85° C (-40° F to +185° F)

Vibration and Shock ..... Standard commercial practice

Operating Input Voltage ..... See "Recorder Specification"

Signal Input Connection ..... Front panel: 2 binding posts (Hi and Lo); Rear panel: Barrier strip (screw type)

Weight (Coupler only) ..... 1 pound (0.45 Kilogram)

Dimensions (Coupler only) ..... 2.125 in. H x 5 in. W x 12.75 in. D (5.4 cm H x 12.7 cm W x 32.4 cm D)

Trim Control ..... Adjusts any full scale sensitivity except the 1 volt range, which is factory set in the pen drive amplifier.

1.4.2 Fixed Span DC Preamplifier 13-4715-07

Measurement Range ..... 1 millivolt full scale to 100 volts full scale, dependent on Range Card selected.

Sensitivity with plug-in Model	11-4601-01 Range Card	1 millivolt full scale
	11-4601-02 Range Card	2 millivolts full scale
	11-4601-03 Range Card	5 millivolts full scale
	11-4601-04 Range Card	10 millivolts full scale
	11-4601-05 Range Card	20 millivolts full scale
	11-4601-06 Range Card	50 millivolts full scale
	11-4601-07 Range Card	100 millivolts full scale
	11-4601-08 Range Card	200 millivolts full scale
	11-4601-09 Range Card	500 millivolts full scale
	11-4601-10 Range Card	1 volt full scale
	11-4601-11 Range Card	2 volt full scale
	11-4601-12 Range Card	5 volts full scale
	11-4601-13 Range Card	10 volts full scale
	11-4601-14 Range Card	20 volts full scale
	11-4601-15 Range Card	50 volts full scale
	11-4601-16 Range Card	100 volts full scale

Inaccuracy	±0.25% of full scale or 2 microvolts (whichever is greater) at 25° C
Input Circuit	Floating and guarded
Input Impedance	Potentiometric (>80 kilohms) from 1 millivolt to 100 millivolts full scale; 1 megohm from 200 millivolts to 100 volts full scale.
Common Mode Rejection	120 dB at dc and 60Hz with 1-kilohm unbalance
Maximum Allowable Input Voltage	220 volts dc or peak ac normal mode or common mode
Zero Line Instability (After 30-minute warm-up	±0.1% of full scale for 24 hours ±0.1% of full scale per °C ±0.05% of full scale per 10% line change
Gain Instability (After 30-minute warm-up)	±0.01% of reading for 24 hours ±0.01% of reading per °C ±0.01% of reading for 10% line change
Output Noise	±0.1% of full scale
Zero Offset	±100% of full scale
Operating Temperature	0° C to 50° C (+32° F to +122° F)
Storage Temperature	-40° C to +85° C (-40° F to +185° F)
Vibration and Shock	Standard commerical practice
Operating Input Voltage	See "Recorder Specification"
Power Input	0.2VA
Weight (preamplifier only)	1 pound (0.45 kilogram)

Dimensions (preamplifier only) ..... 2.125 in. H x 5 in. W x 12.75 D (5.4 cm H x 12.7 cm W x 32.4 cm D)

Signal Input Connection ..... Front panel: 3 binding post; Rear panel; Barrier Strip

1.4.3 Multi-Span D.C. Preamplifier 13-4715-06

Measurement Range ..... 40 microvolts full scale to 100 volts full scale

Attenuator Steps ..... 0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50 and 100 millivolts full scale; 0.1, 0.2, 0.5, 1.2, 5, 10, 20, 50 and 100 volts full scale and OFF

Inaccuracy ..... ±0.25% of full scale or 2 microvolts (whichever is greater) at 24° C ±2° C

Sensitivity Vernier ..... Continuously increases full scale sensitivity up to 3 times.

Input Circuit ..... Floating and guarded

Input Impedance ..... Potentiometric (>80 kilohms) in millivolt mode: 1 megohm in volt mode

Common Mode Rejection ..... Greater than 120 dB at dc and 60Hz with 1 kilohm unbalance

Maximum Allowable Input Voltage ..... 220 volts dc or peak ac normal mode or common mode

Zero Line Instability (After 30-minute warm-up) ..... ±0.1% of full scale for 24 hours
±0.1% of full scale per °C
±0.05% of full scale for 10% line change

Gain Instability (After 30-minute warm-up) ..... ±0.01% of reading for 24 hours
±0.01% of reading per °C
±0.01% of reading for 10% line change

Response Time of Selectable Output Filter

- Full Position ..... 0.25 second full scale maximum
- 0.5 Position ..... 0.5 second full scale ±20%
- 1.0 Position ..... 1.0 second full scale ±20%
- 2.0 Position ..... 2.0 seconds full scale ±20%

Calibrated Zero Offset

- Range ..... ±10 times full scale
- Resolution ..... ±0.1% of zero offset range
- Non-Linearity ..... ±0.5% of zero offset range
- Inaccuracy ..... ±0.5% of zero offset range

Stability (after 30-minute warm-up)

With Time ..... ±0.1% for 24 hours
With Temperature ..... ±0.01% per °C
With Line ..... ±0.1% for 10% line change

Operating Temperature ..... 0° C to +50° C (+32° F to +122° F)

Storage Temperature ..... -40° C to +85° C (-40° F to +185° F)

Vibration and Shock ..... Best commercial practice

Operating Input Voltage ..... See "Recorder Specification"

Power Input 0.1VA

Weight (preamplifier only) ..... 1 ¼ pounds (0.57 kilogram)

Dimensions (preamplifier only) ..... 2.125 in. H x 5 in. W x 12.75 in. D (5.4 cm H x 12.7 cm W x 32.4 cm D)

Signal Input Connection ..... Front panel: 3 binding posts; Rear panel: Barrier Strip

1.5 MODELS

Table 1-1 lists the various models that are available in the 110 series.

PORTABLE RECORDERS (less preamplifiers)	MODEL NUMBER
Single channel, English chart speeds, 115VAC, 60Hz	15-4318-00
Single channel, metric chart speeds, 115VAC, 60Hz	15-4318-10
Dual channel, English chart speeds, 115VAC, 60Hz	15-4328-00
Dual Channel, metric chart speeds, 115VAC, 60Hz	15-4328-10
RACK MOUNTED RECORDERS (less preamplifiers)	**MODEL NUMBER**
Single channel, English chart speeds, 115VAC, 60Hz	15-4618-00
Single channel, metric chart speeds, 115VAC, 60Hz	15-4618-10
Dual channel, English chart speeds, 115VAC, 60Hz	15-4628-00
Dual channel, metric chart speeds, 115VAC, 60Hz	15-4628-10

NOTE: For 230V, 50Hz operation, change last digit in model number suffix from 0 to 6. EX: 15-4318-00 is 115V, 60Hz. 15-4318-06 is 230V, 50Hz. For 115 Volts, 50Hz operation, change last digit from 0 to 5.

TABLE 1-1 GOULD 110 STRIP CHART RECORDER MODELS

1.6 OPTIONS

Table 1-2 lists the options that are available with the Gould 110 strip chart recorder.

OPTIONS (Must be ordered with Recorder)	MODEL NUMBER
Chart Integrator for single channel recorder	11-6105-00
Chart Integrator for dual channel recorder	11-6105-01
Limit Switches for channel one only	11-6103-01
Limit Switches for channels one and two	11-6103-02
Retransmitting Potentiometer (10 Kohms) for channel one	11-6102-01
Retransmitting Potentiometer (10 Kohms) for channel two	11-6102-02

TABLE 1-2 GOULD 110 OPTIONS

1.7 ACCESSORIES

Table 1-3 is a list of accessories that may be purchased with the Gould 110.

ACCESSORIES	MODEL NUMBER
Left margin event marker	11-6222-16
Right margin event marker	11-6222-17
Dust Cover	486821
Servo amplifier extender board	886604
Lockable door (for rack-mounted recorder only)	687009
Starter Kit (Includes 12 rolls of chart paper, gram gage and dust cover)	
English standard	11-6250-06
Metric standard	11-6250-07
English standard with integrator channel on chart	11-6250-08
Metric standard with integrator channel on chart	11-6250-09

TABLE 1-3 ACCESSORIES

1.8 SUPPLIES

Supplies may be ordered with the Gould 110 as listed in Table 1-4.

SUPPLIES	MODEL NUMBER
English chart paper	11-2915-10
Metric chart paper	11-2915-11
English chart paper with integrator channel	11-2915-12
Metric chart paper with integrator channel	11-2915-13
Upper channel stylus	11-2824-36
Lower channel stylus	11-2824-37
Left event marker stylus	11-2874-11
Right event marker stylus	11-2874-12
Integrator stylus	11-2874-33

TABLE 1-4 STRIP CHART RECORDER SUPPLIES

SECTION II

INSTALLATION

2.1 GENERAL

This section contains information necessary to put the recorder into service, including installation of optional equipment.

2.2 SERVICE UPON RECEIPT

Before making signal connections and applying power to the recorder, the following service must be performed:

a. Remove packing material from recorder.

b. Visually inspect unit for damage that may have occurred during shipment.

c. Operate front panel controls (they should turn freely with no binding).

d. Check for free removal and insertion of writing table. There should be no binding in the seats of the end blocks, or the catches in sideplates.

e. Check paper alignment by turning thumbwheel and manually advancing paper. Allow paper to feed out of the unit while observing that holes in paper align with sprocket teeth and paper tracks smoothly without obstruction to paper travel.

f. To check internal take-up, remove writing table and attach free end of paper to take-up core with tape. Manually advance paper by turning thumbwheel. Paper should wind onto take-up core reasonably tight without overriding sprockets.

g. Install rack-mounted models as shown in Figure 2-1.

2.3 PREAMPLIFIERS

2.3.1 Input Signal Coupler (13-4715-08)

a. Insert signal coupler into the recorder mainframe (component side up) being certain that the module is guided into the printed circuit card holder grooves of the recorder mainframe. Push the signal coupler all the way in, the board should mate with the rear card connector.

b. Rotate "OFFSET" knob. This control should turn freely without binding or scraping.

2.3.2 Fixed Span (13-4715-07) and Gain Module(s)

a. Insert gain module card (11-4601-xx) into front panel rectangular opening (component side up) of the fixed span preamplifier.

b. When gain module card is inserted into card edge connector, the handle base of the module should be flush with the front panel of the preamplifier.

c. Rotate "OFFSET" knob. This control should turn freely without binding.

d. Inspect the three front input terminals on the preamplifier. The terminals should be tight and not turn as the wire securing nut is tightened or loosened.

e. Insert the preamplifier into the recorder mainframe being certain that the hole in the preamplifier securing brackets line up with the holes in the recorder mainframe.

2.3.3 Multi-Span (13-4715-06)

a. Rotate all knobs on the preamplifier front panel. There should be no binding or scraping.

b. Inspect the three front input terminals on the preamplifier front panel. The binding posts should be tight and not turn as the wire securing nut is tightened or loosened.

c. Insert the preamplifier into the recorder mainframe being certain that it is not binding and the front panel does not interfere with other panel surfaces.

d. When the preamplifier is inserted into the recorder, be certain that the holes in the preamplifier securing brackets line up with the holes in the recorder mainframe.

2.4 ELECTRICAL CONNECTIONS

2.4.1 Signal Connections

Input signal connections are made via binding post terminals located on the preamplifier front panel (two posts for a signal coupler, three posts for fixed or multi-span preamplifiers) or rear input

connection terminal strips (see Figure 3-2) located at the rear of the recorder. For high level signal source applications the LOW input terminal should be jumpered to the GD (guard) input terminal (see Figures 2-2 and 2-4). For low (millivolt) level signal source applications connect the GD terminal to the input cable shield. The other end of the cable shield should be jumpered to the low side of the signal source which should also be grounded (see Figures 2-3 and 2-5).

2.4.2 AC Power Input

Unwind power cable from rear retainer and connect to correct power source.

2.4.3 Remote Chart Drive Control

For remote chart drive operation, remove jumper between pins 3 and 4 on rear panel terminal strip (see Figure 3-2). Apply external switch closure to activate chart drive.

2.4.4 External Chart Drive

For external pulse drive, remove jumper between pins 1 and 2 on rear terminal strip (see Figure 3-2). Set chart speed selector on front panel to "R" position. Apply pulse input from appropriate source to terminals 1 and 2.

2.4.5 Options

Options are connected via terminal strips located on the rear panel of the recorder (see Figure 3-2).


23 WASHER, PLAIN
BRACKET ASS'Y. R.H. 20
22 LOCKWASHER, SPRING
10 4-40 x 1/4 LG. PAN HD., SELF-TAP
21 8-32 x 1/2 LG. PAN HD.
9 10-32 x 1/2 LG. FLAT HD.
3 COVER
8 10-32 x 1-1/8 LG. PAN HD. ORNAMENTAL
1 10" STRIP CHART RECORDER ASS'Y.
19 BRACKET ASS'Y. L.H.
2 SADDLE
7 10-32 x 1/2 LG. PAN HD., SELF-TAP
4 NUT BAR
CABINET RAIL (19" RETMA)
5 SPACER BAR
6 TRIM STRIP

NOTES:
1. NUMBERS IN CIRCLES INDICATE ITEM NUMBERS.
2. ITEM 1 IS IDENTICAL TO THE 15-4318-00 AND 15-4328-00 SERIES OF RECORDERS EXCEPT THE CARRYING CASE IS REMOVED FOR RACK MOUNTING.
3. ASSEMBLE ITEMS 2, 4 & 5 TO FRONT CABINET RAILS USING ITEM 9.
4. MOUNT ITEM 1 IN ITEM 2 WITH ITEM 7.
5. INSTALL ITEM 3 USING ITEM 10.
6. INSTALL ITEM 6 USING ITEM 8.

REVISIONS

REV.	DESCRIPTION	DATE	APPROVED
A-1	ADDED ITEMS 19 THRU 23. DCN/20714	10/24/74	DTH

15-4618-16	15-4628-16
15-4618-10	15-4628-10
15-4618-06	15-4628-06
15-4618-00	15-4628-00

APPLICABLE FOR ABOVE MODELS

NO.	BRUSH PART NO	DESCRIPTION	REQ'D
23	1-118195-307	WASHER, PLAIN	4
22	1-216741-425	LOCKWASHER, PLAIN	4
21	31-119918-8208	SCREW, PAN HD.	4
20	788041	BRACKET ASS'Y. R.H.	1
19	788043	BRACKET ASS'Y. L.H.	1
18	687001	SHIP. LIST & INSTALL. INST.	1
17	222640	CARD, CONCEALED DAMAGE	1
16	15-804318-00	MANUAL, OPERATING	1
15	422642	ENVELOPE, MANUAL	1
14	283549-1	CORE, PAPER WOUND	1
13	684845	BUSHING ASSY. SUPPLY ROLL	1
12	684844	BUSHING ASS'Y. TAKE-UP	1
11	CABINET	19" RETMA	-
10	13-262716-4004	SCREW, SELF-TAP	6
9	31-119920-0208	SCREW, FLAT HD.	4
8	248352-0218	SCREW, PAN HD.	4
7	13-262716-0208	SCREW, SELF-TAP	4
6	286887	STRIP, TRIM	2
5	286992	BAR, SPACER	2
4	286892	BAR, NUT	2
3	386993	COVER, SADDLE	1
2	386994	SADDLE, RACK MTG.	1
1	SEE MODELS LISTED	RECORDER ASS'Y.	-

SHIPPING LIST

DR. L.KISNER 7/1/74	SHIPPING LIST & INSTALLATION INSTRUCTIONS	Gould Inc. Instrument Systems Division Cleveland, Ohio 44114 U.S.A.	
CH.	SIZE A	CODE IDENT. 96795	DRAWING NO. 687001
APP.	SCALE		

FIGURE 2-1 SHIPPING LIST AND INSTALLATION INSTRUCTIONS FOR RACK MOUNTED MODELS (687001)



NOTES:

1. NUMBERS IN CIRCLES INDICATE ITEM NUMBERS.
2. REMOVE THE PAINTED TRIM STRIP FROM EACH SIDE AND THE NYLON WASHERS FROM EACH OF THE 4 MOUNTING SCREWS.
3. INSTALL ITEMS 3 & 4 ON THE LEFT SIDE AND ITEM 5 ON THE RIGHT SIDE USING THE SAME SCREWS. DO NOT TIGHTEN.
4. INSTALL ITEM 6 ON ITEM 2 WITH CAM ARM TOWARD TOP OF UNIT.
5. INSTALL ITEM 2 ON ITEM 3 USING ITEMS 7, 8 & 9. DO NOT TIGHTEN.
6. ADJUST DOOR FOR PROPER CLEARANCE AROUND ITEM 5. OBSERVE THAT LOCK HAS SUFFICIENT CLEARANCE TO OPERATE. TIGHTEN ALL HARDWARE.

REVISIONS			
SYM.	DESCRIPTION	DATE	APPROVAL

15-4618-16	15-4628-16
15-4618-10	15-4628-10
15-4618-06	15-4628-06
15-4618-00	15-4628-00
APPLICABLE FOR ABOVE MODELS	

NO.	BRUSH PART NO.	DESCRIPTION	QTY
20			
19			
18			
17			
16			
15			
14			
13			
12			
11			
10	687009	SHIP. LIST & INSTAL. INST.	1
9	31-119998-40	NUT, HEX.	3
8	1-216741-411	LOCKWASHER	3
7	1-118195-304	WASHER, PLAIN	3
6	687003	LOCK ASS'Y.	1
5	287002	STRIP, TRIM	1
4	286885	STRIP, TRIM	1
3	786995	HINGE ASS'Y.	1
2	486996	DOOR, RACK MTG.	1
1	SEE LIST ABOVE	RECORDER ASS'Y.	-

SHIPPING LIST

DR. KISNER 1/26	SHIPPING LIST & INSTALLATION INSTRUCTIONS FOR LOCKABLE DOOR	Brush Inc. Instrument Systems Division Cleveland, Ohio 44114 U.S.A.	
CH. 1/26			
APP. 1/26	CODE IDENT 96795	SIZE	687009

687009

2.3a

FIGURE 2-2 SHIPPING LIST AND INSTALLATION INSTRUCTIONS FOR LOCKABLE DOOR (RACK MOUNTED MODELS) (687009)



FIGURE 2-3 HIGH LEVEL, GROUNDED, SIGNAL SOURCE



FIGURE 2-4 MILLIVOLT LEVEL, GROUNDED, SIGNAL SOURCE



FIGURE 2-5 HIGH LEVEL, FLOATING, SIGNAL SOURCE



FIGURE 2-6 MILLIVOLT LEVEL, FLOATING SIGNAL SOURCE

Information contained herein is considered proprietary to GOULD INC. INSTRUMENT SYSTEMS DIVISION. Release of this information is to facilitate the servicing and maintenance of Gould equipment only.

Under no circumstances shall this information be transmitted, reproduced, disclosed to, or used by any person or organization other than those engaged in such activities, without the express written consent of GOULD INC. INSTRUMENT SYSTEMS DIVISION.



NOTES:

1. NUMBERS IN CIRCLES INDICATE ITEM NUMBERS.
2. INSTALL ITEM 2 USING ITEMS 6, 7 & 8. TWIST WIRES TOGETHER AS SHOWN, SOLENOID SHOULD BE ADJUSTED TO GIVE APPROX. 20 GRAMS PRESSURE ON PEN WHILE WRITING.
3. INSTALL ITEM 1 USING ITEMS 3, 4 & 5. ADJUST PEN TO WRITE ON THE MARGIN FROM .02 - .07 INCHES BEYOND THE OUTERMOST VERTICAL GRIDLINE. WITH THE SOLENOID DEENERGIZED THE PEN SHOULD REST APPROX. .05 INCHES ABOVE THE WRITING SURFACE.
4. INSTALL ITEM 9 USING ITEMS 10 & 13 AND CAPTIVATE WIRES FROM ITEMS 1 & 2.
5. INSTALL ITEM 11. MOUNT 4 PIN CONNECTOR ON SIDE PLATE AS SHOWN USING ITEMS 12, 13 & 14. ROUTE HARNESS ACROSS REAR OF PEN DRIVE PLATE AND THRU NOTCH IN R.H. SIDE PLATE. CONNECT 6 PIN CONNECTOR ON MAIN CONTROL BOARD AS SHOWN.
6. INSTALL ITEM 15 TO REAR TERMINAL PANEL USING ITEMS 6, 7 & 8. ATTACH INDICATED WIRES FROM HARNESS TO REAR OF TERMINAL BOARD, (CONTACTS MARKED FOR L.H. EVENT) AS SHOWN.





SPRING
HD.

REVISIONS

SYM.	DESCRIPTION	DATE	APPROVAL
A-1	ITEM-5 WAS: 1-118195-301		
A-2	ITEM-8 WAS: 11305-21 DCN 20754	11.5.74	

NO.	BRUSH PART NO.	DESCRIPTION	QUAN
	SHIPPING LIST		
20		STRIP CHART RECORDER	-
19	686747	SHIP.LIST & INSTAL.INST.	1
18	31-119998-62	NUT, HEX.	2
17	1-216741-420	LOCKWASHER, SPRING	2
16	31-119918-6210	SCREW, PAN HD.	2
15	1-286155-4	BOARD, TERMINAL	1
14	31-119998-26	NUT, HEX.	2
13	1-216741-402	LOCKWASHER, SPRING	3
12	31-119914-2607	SCREW, PAN HD.	2
11	886556	HARNESS ASS'Y.	1
10	31-119914-2602	SCREW, PAN HD.	1
9	285103	CLIP	1
8	2-118195-202	WASHER, FLAT	2
7			
6	31-119914-1202	SCREW, PAN HD.	2
5	285511-1	WASHER, FLAT	2
4	128777-102	LOCKWASHER, SPRING	2
3	31-119914-0003	SCREW, PAN HD.	2
2	686672	SOLENOID ASS'Y.	1
1	11-2874-12	STYLUS ASS'Y. L.H.EVENT	1

BY	DATE
DR KISNER	9/20/74
CH	11/5/74
ENG Petrun	11.5.74

NAME: SHIPPING LIST & INSTALLATION INSTRUCTIONS

CODE IDENT: 96795 ISSUE CODE: G

Gould Inc.
Instrument Systems Division
Cleveland Ohio 44114 U.S.A.

DWG NO: 686747

FIGURE 2-7 LEFT MARGIN EVENT MARKER (11-6222-16)

Information contained herein is considered proprietary to GOULD INC., INSTRUMENT SYSTEMS DIVISION. Release of this information is to facilitate the servicing and maintenance of Gould equipment only.

Under no circumstances shall this information be transmitted reproduced, disclosed to, or used by any person or organization other than those engaged in such activities without the express written consent of GOULD INC., INSTRUMENT SYSTEMS DIVISION.



NOTES:

1. NUMBERS IN CIRCLES INDICATE ITEM NUMBERS.
2. INSTALL ITEM 2 USING ITEMS 6, 7 & 8. TWIST WIRES TOGETHER AS SHOWN. SOLENOID SHOULD BE ADJUSTED TO GIVE APPROX., 20 GRAMS PRESSURE ON PEN WHILE WRITING.
3. INSTALL ITEM 1 USING ITEMS 3, 4 & 5. ADJUST PEN TO WRITE ON THE MARGIN FROM .02 - .07 INCHES BEYOND THE OUTERMOST VERTICAL GRIDLINE. WITH THE SOLENOID DEENERGIZED THE PEN SHOULD REST APPROX. .05 INCHES ABOVE THE WRITING SURFACE.
4. INSTALL ITEM 9 USING ITEMS 10 & 13 AND CAPTIVATE WIRES FROM ITEMS 1 & 2.
5. INSTALL ITEM 11. MOUNT 4 PIN CONNECTOR ON SIDE PLATE AS SHOWN USING ITEMS 12, 13 & 14. ROUTE HARNESS ALONG SIDE PLATE AND THROUGH NOTCH. CONNECT 6 PIN CONNECTOR ON MAIN CONTROL BOARD AS SHOWN.
6. INSTALL ITEM 15 TO REAR TERMINAL PANEL USING ITEMS 16, 17 & 18. ATTACH INDICATED WIRES FROM HARNESS TO REAR OF TERMINAL BOARD, (CONTACTS MARKED FOR R.H. EVENT) AS SHOWN.



SYM.	REVISIONS DESCRIPTION	DATE	APPROVAL
A-1	ITEM-5 WAS: 1-118195-301		
A-2	ITEM-8 WAS: 11305-21 DCN 20754		

NO.	BRUSH PART NO.	DESCRIPTION	QUAN
	SHIPPING LIST		
20	———	STRIP CHART RECORDER	-
19	686749	SHIP. LIST & INSTAL. INST.	1
18	31-119998-62	NUT, HEX.	2
17	1-216741-420	LOCKWASHER, SPRING	2
16	31-118818-6210	SCREW, PAN HD.	2
15	1-286155-4	BOARD, TERMINAL	1
14	31-119998-26	NUT, HEX.	2
13	1-216741-402	LOCKWASHER, SPRING	3
12	31-119920-2607	SCREW, FLAT HD.	2
11	886554	HARNESS ASS'Y.	1
10	31-119914-2602	SCREW, PAN HD.	1
9	285103	CLIP	1
8	2-118195-202	WASHER, FLAT	2
7			
6	31-119914-1202	SCREW, PAN HD.	2
5	285511-1	WASHER, FLAT	2
4	128777-102	LOCKWASHER, SPRING	2
3	31-119914-0003	SCREW, PAN HD.	2
2	686672	SOLENOID ASS'Y.	1
1	11-2874-11	STYLUS ASS'Y, R.H. EVENT	1

BY	DATE	NAME	Gould Inc. Instrument Systems Division Cleveland, Ohio 44114 U.S.A.
DR KISNER	9/27/74	SHIPPING LIST & INSTALLATION INSTRUCTIONS	
CH Ignacio	10/15/74	CODE IDENT. 96795	ISSUE CODE G
APP	9/14/74		DWG NO. 686749

FIGURE 2-8 RIGHT MARGIN EVENT MARKER (11-6222-17)

SECTION III

OPERATION

3.1 GENERAL

This section describes and illustrates the steps necessary to operate the recorder.

3.2 FRONT PANEL CONTROLS AND INDICATORS

Figure 3-1 illustrates the front panel controls and indicators. The following list corresponds to the items called out in the illustration.

ITEM	CONTROL/INDICATOR	DESCRIPTION
1	Balance Control	Balance control enables user to balance integrator unit for maximum drift with zero analog input.
2	Balance Pushbutton	Balance pushbutton overrides chart paper interlock, enabling user to balance integrator unit with writing table removed.
3	Limit Indicator (Upper)	Limit switch indicator provides left and right out-of-limit indications for upper channel.
4	Scale	Upper channel scale.
5	Scale	Lower channel scale.
6	Scale	Integrator pen scale.
7	Span (fixed span)	Plug-in range cards provide 16 fixed sensitivities from 1 millivolt full scale to 100 volts full scale (2 volt full scale card shown), on the fixed span pre-amplifier.
8	TRACE DENSITY	The outer knob controls the pen tip heat for all stylii. The inner control is a fine heat adjustment for the lower channel only.
9	CHART SPEED	Provides "remote" pulse input operation as well as ten chart speeds. CAUTION: WHEN DRIVING CHART FROM AN EXTERNAL PULSE SOURCE, THE EXTERNAL DRIVE OVERRIDES THE END OF CHART SHUT-OFF CIRCUITRY. WHEN PAPER RUNS OUT, THE USER MUST STOP THE CHART DRIVE BY EITHER STOPPING THE EXTERNAL PULSES, OPENING THE REMOTE SWITCH CLOSURE (IF USED), SWITCHING THE CHART SPEED CONTROL OUT OF "R" (REMOTE), OR OPERATING THE CHART STOP CONTROL.
10	CHART STOP	A two-position switch that controls the start/stop chart drive motor.
11	POWER	Two-position switch that controls the on/off prim - ary power to the recorder mainframe plug-in module and options.

ITEM	CONTROL/INDICATOR	DESCRIPTION
12	Signal Connectors	Input signal terminals (fixed gain preamplifier).
13	Signal Connectors	Input signal terminals (multi span preamplifier).
14	OFFSET (fixed span)	OFFSET control sets pen zero between ±1 full scale from right hand chart edge on the fixed span preamplifier.
15	–, +, OFF	Three-position switch selects plus, minus, or off for OFFSET control on the multi span preamplifier.
16	OFFSET (multi-span)	Calibrated zero OFFSET up to 10x full scale on the multi span preamplifier. Provides resolution for portions of a signal equivalent to a 100-inch chart.
17	RESPONSE	RESPONSE switch on multi span preamplifier selects FULL (250 millisecond), 0.5, 1, or 2 second response time. Last three positions introduce internal filters with lower cutoff frequencies. Coaxial two-position switch determines whether span sensitivity is volts or millivolts.
18	SPAN (multi-span)	SPAN switch on the multi span preamplifier selects sensitivities of 0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, or 100 volts or millivolts full scale. Coaxial vernier control adjusts sensitivity range between attenuator steps.
19	Limit Switches (Upper)	Provides two independent limit switch set points for the upper analog channel.
20	Limit Switches (Lower)	Provides two independent limit switch set points for the lower analog channel.
21	Limit Indicator (Lower)	Limit switch indicator provides left and right out-of-limit indications for lower channel.



FIGURE 3-1 FRONT PANEL CONTROLS AND INDICATORS

3.3 REAR PANEL CONNECTIONS

Figure 3-2 illustrates the rear panel connections. The following list corresponds to the items called out in the illustration.

ITEM	CONNECTOR	DESCRIPTION
1	Power Cord	Connect to proper ac outlet.
2	Fuse Holder	Contains slow-blow fuse.
3	Retransmitting Potentiometer	Provides connection(s) to optional potentiometer(s) for one or two channels.
4	Limit Switch	Terminal provides connection to internal (front adjustable) upper and lower optional control limit switches.
5	Drive Amplifier	Plug-in drive amplifier boards.
6	EVENT MARKER	Event marker terminals connect to optional right and left hand event markers.
7	Remote Start	Remote start terminals (pins 3 and 4) to actuate the chart drive motor from a remote switch closure (when chart speed is internally selected).
8	PULSE INPUT	Pulse input terminals (pins 1 and 2) for driving chart from external pulse source. CAUTION: SEE NOTE, THIS SECTION, PARAGRAPH 3.2, ITEM 9.
9	Signal Input	Input terminals for single or dual channels may be used in lieu of front panel input terminals on preamplifiers.

3.4 WRITING TABLE

For optimum viewing, the writing table may be positioned at any of three angles: vertical, 15° or 30°. To change from one position to the other, grasp the sides of the writing table and move it to the desired position. To remove writing table, raise table to 90° position and pull out.

3.5 PEN HEAT CONTROL

Trace density is adjusted by rotating the outer TRACE DENSITY knob (see Figure 3-1) until the desired line density is obtained. The smaller inner knob is the trace density vernier and is used when small changes in lower channel trace density are desired.

NOTE: The inner trace density vernier knob may be used to reduce the density of the lower channel trace only.

In model number 15-4328-xx (standard lower channel, plus an upper channel) the density vernier may be used to adjust the density of the lower channel for optimum channel identification.

3.6 SETUP AND OPERATION

3.6.1 General

This section lists the logical sequence of steps necessary to supply signals and operate the recorder. Perform the following procedure:



FIGURE 3-2 REAR PANEL CONNECTIONS

CAUTION: BEFORE APPLYING A SIGNAL TO THE RECORDER, VERIFY THAT THE INPUT VOLTAGE DOES NOT EXCEED THE LIMIT FOR THE PREAMPLIFIER USED. SEE SECTION I, FOR PREAMPLIFIER SPECIFICATIONS.

a. Check paper supply level. Make certain an adequate supply is present for length of time recorder is to be operated and that it is properly threaded. See Section VI, chart paper installation, and Section II for checking paper alignment.

b. Make certain that the CHART and POWER switches are off (down).

c. Make electrical connections to the recorder per Section II. Make certain the guard GD terminal is jumpered to the LOW input terminal as described.

d. Place POWER switch in the on (up) position. POWER lamp should illuminate.

e. Obtain a zero input signal as follows:

1. Multi-Span DC Preamplifier (13-4715-06) — no action required. Multi-Span pen zeroing done in Section VII, Calibration.

2. Fixed Span DC Preamplifier (13-4715-07) — partially remove the range card far enough (about 1") to disconnect it.

3. Input Signal Coupler (13-4715-08) — disconnect the signal wires from the input terminals.

f. Place CHART switch in the start (up) position. CHART lamp should illuminate and chart paper should move.

g. Adjust the OFFSET control(s) to zero the pen(s) at the desired position (Fixed Span Preamp and Input Signal coupler only).

h. Restore the input signal.

j. On the Multi-Span Preamp, set the SPAN, RESPONSE, and OFFSET controls as required for the application.

k. Set CHART SPEED and TRACE DENSITY controls to best display signal.

l. For increased accuracy on the Input Signal Coupler, the TRIM control may be used to precisely calibrate any full-scale sensitivity except the 1 volt range, which is factory set in the pen drive amplifier.

3.7 INTEGRATOR OPERATION

No operator controls are required. Please see Section IV, Theory of Operation, for an explanation of proper usage of this option. Also see Section VII, Calibration, for complete adjustment procedures.

SECTION IV

THEORY OF OPERATION

4.1 GENERAL

This section describes the theory of operation, including a circuit description, for both the recorder and its preamplifiers. Figure 4-1 illustrates the basic recorder in block form.

4.2 RECORDER CONTROL ASSEMBLY

4.2.1 General

The recorder control assembly (Figure 4-2) is part of the strip chart recorder mainframe. The assembly (885088) consists of the following circuitry:

AC Distribution
Pen Heat Control
End of Chart
Stepper Motor Chart Drive
115/230 Volt Switching
External Chart Pulse Drive
Event Marker Control
Power Supply



FIGURE 4-1 RECORDER BLOCK DIAGRAM



FIGURE 4-2 RECORDER CONTROL ASSEMBLY BLOCK DIAGRAM

4.2.2 AC Distribution

Voltage at the plus corner of CR108 rises, (see Figure 4-3) causing the base two voltage of Q104 to rise. As this is occuring, capacitors C108 and C109 (above 2in/min only-C108 is in the circuit) are charging exponentially. When the emitter voltage reaches the firing point of Q104, capacitors C108 and C109 discharge. The emitter-base-one presents an extremely low impedance at firing point. This current pulse flows through transformer winding T102, light coupler U102 (4N28) and relay contacts K101 to common ground. The current pulse through the primary winding of T102 causes a pulse to flow to the gate-cathode junction of the silicon controlled rectifier CR109. turning it on. The action of turning on CR109, shuts off unijunction Q104, sensing it for the next V2 cycle of line voltage. The delay time before CR109 is turned on is controlled by R301-1 TRACE DENSITY. R301-1 is part of the R in the RC circuit. Resistor R117 is factory set to limit the maximum pen heat voltage. R142 is in parallel with the L.E.D. portion of U102 stopping the half wave sine from modulating. This is accomplished by providing a low impedance path to common ground and allowing only the current pulse to appear across R122 and common ground.

When relay K101 is de-energized, the capacitor discharge path is interrupted. This action prevents the transmission circuit from receiving its timing pulse, causing the chart to stop.

The pen heater voltage may be measured at TP4 and TP5. Use a true RMS volt meter which also responds to DC levels. Capacitor C109 is out of the circuit in chart speeds above 1 in/hr.,thus raising the pen heater voltage in those speeds.



FIGURE 4-3 RECORDER THEORY OF OPERATION DIAGRAM

4.2.3 End of Chart Circuitry

The end of chart circuit (Figure 4-3) employs a led emitter-sensor package (U401) to sense the presence of chart paper or a paper jam condition. When paper runs out, the black anodized drive roll is exposed to U401, causing the voltage at pin 2 (U101) to become more negative. This action causes the output of U101 to become positive, turning off Q101. When Q101 is turned off, relay K101 is de-energized. Relay K101 controls the chart drive and pen heat voltage. When K101 is de-energized and CHART switch is on (up), the chart switch lamp is extinguished indicating a paper jam or paper out condition. Resistor R101 (end of chart sensitivity adjust) adjusts the point where relay K101 energizes, compensating for variations in U401.

CAUTION: WHEN DRIVING CHART FROM AN EXTERNAL PULSE SOURCE, THE EXTERNAL DRIVE OVERRIDES THE END OF CHART SHUT-OFF CIRCUITRY. WHEN PAPER RUNS OUT, THE USER MUST STOP THE CHART DRIVE BY EITHER STOPPING THE EXTERNAL PULSES, OPENING THE REMOTE SWITCH CLOSURE (IF USED), SWITCHING THE CHART SPEED CONTROL OUT OF "R" (REMOTE), OR OPERATING THE CHART STOP CONTROL.

4.2.4 Stepper Motor Circuitry

The CHART SPEED knob on the recorder front panel is connected to the stepper motor circuit. The stepper motor circuit (see Figure 4-3) receives 8.33 or 10 millisecond positive pulses across resistor R122, dividing the frequency to obtain the desired chart speeds. In the fastest chart speed, 8"/min., pulses from U102 (terminal 4) drive the four-phase encoder U106 (A and B) directly without dividing the frequency. The frequency is divided according to the CHART SPEED setting as follows: 4in./min-pulses are divided by two, 2in./min-pulses are divided by four, etc. At setting 1in./hr. (2.50 cm./hr.) pulses are divided by 480, resulting in a pulse every four seconds for a 60Hz line.

Divisions of 2, 4, 8, and 16 are provided by U103 (dual binary up-counter) via R122. U103 and U104 form a divide by ten circuit. U104 is used as an inverter. U104-A functions as a coincidence circuit. U104-DC and U105-A, B constitute a divide by three with U104-D acting as the coincidence circuit. U104-C resets U105-A and B. Output in the slowest chart speed comes from pin 13 of U105-A and goes to S103, position 1 (1in./hr or 2 ½ cm/hr.). Pin six of S103 (rotor) receives front-panel-selected pulses and feeds them to the four-phase encoder. The four outputs from U106-A, B are connected to four pairs of driver transistors, Q105 through Q112. Two of the stepper motors four windings are always energized.

4.2.5 115/230 Volt Switching

The 115/230 volt AC switching (Figure 4-3) is accomplished by jumpers. Transformers T101, T401-1, and T401-2, (T401-2 only when second channel is present) have dual primaries (parallel for 115V and series of 230V ac lines.

4.2.6 External Chart Drive Pulse

When the CHART SPEED selector knob is turned to the "R" position, U106-A and U106-B are driven from Q102 and Q103. Both Q102 and Q103 comprise a Schmidt trigger circuit enabling the external drive signal to be a wide range of shapes (square and sine wave). This circuit is necessary since U106-A and U106-B are positive edge triggered and require a 5 usec., or less time on their inputs.

4.2.7 Event Marker Control

Switch closures at TB402-1, 2 (for right event) and TB402-3, 4 (for left event) cause current to flow through event marker solenoids (see Figure 4-3). This current flow causes the pen-heater assembly to drop down on the paper for as long as the contacts are closed. R141 is the event marker heater dropping resistor. CR101 and CR102 are transient suppressors.

4.2.8 Power Supply

The ±12 volt power supply provides postive voltage to the following circuits; pen heat, step motor drive, event markers, and Schmidt trigger. The end-of-chart circuit and paper out relay (K101) receive -12 volts from the same power supply.

T101 and CR107 (see Figure 4-3) are in a fullwave bridge circuit with C105 and C106 as filter capacitors.

4.3 DRIVE AMPLIFIER

The drive amplifier controls pen positioning and prevents damage to the pen when the input voltage is too great.

The drive amplifier is a servo system using a potentiometer in the feed back loop to control pen positioning. The loop is stabilized by derivitive feedback from the position signal. Figure 4-4 is a schematic drawing illustrating the drive amplifier, including channel power supplies from the preamplifier and other options. Table 4-1 lists the terminal connections for each power supply.

POWER	PIN NUMBERS
±24 volts	13, 15, 20, 22
±15 volts	4, 5, 11, 12, D, E
±6 volts	6, 7, 8, 9, F, H, J, K
Common Terminals	3, 14, 21, C

TABLE 4-1 POWER SUPPLY PIN CONNECTIONS

The input signal is amplified (U204) by a factor of twelve. Current introduced by R221 and R219 condition the input signal so that for a zero to one volt input signal, the output of U204 changes from plus six to minus six volts. When input voltage to U204 is negative, or larger than one volt, the output is limited by the action of U203, CR205, or U204, CR206.

Feedback signals from position potentiometer R401 are monitored by a high input impedance from U209. Output from U209 is used as the position feedback for the servo amplifier. The derivitive of this signal is taken using C212 with amplifiers U208 and U206, which is used as the damping for the servomechanism.

The servo amplifier consists of U207 and a class B power stage (Q205, Q206, Q209, and Q210). The following signals; position, damping, and conditioned input, are summed at the input to the servo amplifier (U207). The servo amplifier drives the motor until the position feedback signal is equal to the conditioned input signal. Diodes CR207 and CR208 conduct when there are large signal variations bringing the gain to 300, independent of frequency. For small signal variations, servo gain acts similar to an integrator with a high DC gain and a corner frequency of 200Hz. In this gain, the high frequency gain also approaches 300.

Removing the writing table de-energizes relay K101, causing the motor and servo amplifier to be disconnected.



FIGURE 4-4 DRIVE AMPLIFIER THEORY OF OPERATION DIAGRAM

4.4 INTEGRATOR

The integrator is an option that records the area under the curve of the analog input signal. This display occupies a 0.975 inch wide chart strip located to the right of the analog channel display (Figure 4-5). The integrator pen traverses the 0.975 inch chart section once for every volt-second or 100 counts of integration, then reverses its direction for the next segment. Determination of the integral of a complex curve over a given time is a matter of counting the number of full scale excursions plus the partial full scale count. A blip is placed at the excursion every 600 or 1000 counts to aid in count retrieval at slow chart speeds. The blip appears on the up scale peaks for positive integration and on the down scale peaks for negative integration.

The active elements of the integrator are U101-3, C102, R116, and R120 (see Figure 8-27). Operational amplifiers U101-1 and U101-2 provide a signal of opposite polarity which is applied to R116 or R120 as Q101-1 or Q101-2 is turned on or off. When Q101-1 is off and Q101-2 on, the signal from U101-1 drives the integrator by shorting the signal from U101-2 to ground. When a positive voltage is applied to input terminal 14 the output of U101-1 becomes negative, causing the integrator to move in the positive direction. When Q101-1 is on and Q101-2 is off, the integrator input is from U101-2. With the same plus voltage applied to the input (terminal 14) the signal driving the integrator is positive due to U101-2. Operational amplifier U101-2 inverts the signal causing the integrator to move in the negative direction.

The signal which controls Q101-1 and Q101-2 is generated by the comparitor (U101-4). As the output of U101-3 (terminal 8) rises, a point is reached where the voltage at U101-4 (terminal 13) makes a transition from minus to plus. This action causes the output voltage of U101-4 (terminal 14) to rise, switching Q101-1 and Q101-2 to reverse the polarity of integration. The point of transition, or peak voltage of the integrator output wave form is determined by resistors R123, R124, R160 and R161.

When the voltage at U101-3 (terminal 8) reverses, the next transition point is determined by resistors R124, R123, R157 and R163. Note that R157 and R163 were not used in the first sweep. (Q101-3 was held on by U101-4). If the input polarity reverses U102-1 switches, reversing the integrator command signal to U101-4 and resistors R157, R163, R160, and R161.



FIGURE 4-5 INTEGRATOR DISPLAY AREA

R155, Polarity sense offset adjust, overcomes the offset voltage of comparitor U102-1 enabling it to switch with less than 1 millivolt change above and below its reference, common term No.5.

The one volt input fullscale time for upscale and downscale integration traverses is calibrated by adjusting the gains of U101-1 and U101-2.

R151, integrator baseline balance, adjusts the integrator drift to minimum by canceling out residual input currents from the preamp and compensating for the offset of U101-1. R151 is initially adjusted at the factory while Q101-1 is off and Q101-2 is on (TP-9 at approximately -4.5 volts) so that U101-2 offset can not influence the integrator drift.

R112, Baseline balance, is used to compensate for resistor tolerance effects and the offset voltage of U101-2. R112 is adjusted with Q101-2 off (TP-9 at +.7 volts). The offset balancing of R151 (above) and R133 must be done in this way so as to get a true balance without one setting influencing the other. R112 is a factory set adjustment which seldom needs further adjustment. The balance adjustments must be made before final Full Scale time Calibration can be made.

U102-2, besides functioning as a precision invertor, is also a buffer amplifier for the integrator signal from U101-3. This buffered integration signal (triangle wave) is summed in R139 and R140. The mid point, terminal 11 of P101, is shorted to common when the paper supply is exhausted. R139 & R140 are integrator signal summing resistors for U102-3, the servo op amp.

TP-2, alternation reversal signal, is used to drive Q101-3 & Q101-4, as described. However, this signal is a square wave whose rise times coincide with the reversals in the integrator triangle wave. This timing signal is used to drive U105, a 4 bit binary counter. The circuit is arranged so that divide by 3 or divide by 5 functions can be switch selected. Since one cycle of this timing signal equals 200 counts, 3 cycles are equal to six hundred counts. This square wave (TEST POINT 8) is capacitively coupled to the normally on base of Q102-3. When the negative transition occurs it turns off Q102-3 for approximately 20 milliseconds. This off time is determined by R-121 and C103. When Q102-3 is off the base of Q102-4 goes to +12V turning Q102-4 on. When this happens the collector of Q102-4, which was at approximately 3.9V, is switched to common for 20 milliseconds. This causes a pip to occur at the peak of the triangle wave (integrator signal).

Since Q102-4 gets its collector supply voltage from the output of U102-1, which is the polarity sense comparitor, the direction of the pips is shifted when the signal polarity changes. The collector voltage of Q102-4 is summed into U102-3 thru R-135.

TP-7 is the drive signal which turns complimentary output pair Q105 or Q106 on or off causing the servo motor to drive one direction or the other. R145 & R146 serve to limit current thru B101.

R134 is the position control for centering the integrator signal in the center of the integrator chart grid. R137, R136 & R138 are voltage division and voltage summing networks for servo position.

Q105 & Q106 common emitters drive servo motor B101. B101 has a 10:1 reduction whose output positions a sector. The position feedback pot, R162, has approximately 12 volts across it. The wiper of the position feedback pot picks up a voltage which is proportional to pen position. This voltage is buffered and amplified by U102-4 which provides high input impedance and adjustable gain. R149, span adjust, controls the gain of U102-4 which determines how far the motor will have to drive the pen before equilibrium is established. Equilibrium is established when the instantanious integrator signal current equals the current which results from the voltage at the output of U102-4 and R142, position feedback summing resistor.

C106, R141 and damping adjust pot R143 allow the pen response to be properly set for constant amplitude. Damping is properly adjusted when the 400% of full scale amplitude is the same as that produced by a 1/10 of full scale signal.

C107 provide for AC feedback while allowing high D.C. gain for accurate positioning of the pen. R144 is a feedback summing resistor for U102-3.

U106 & U107 are positive and negative voltage regulators whose output is + and -12 volts. C109 & C111 are required on the input to the regulators to provide stability. C108 & C110 are for filtering and improved transient reponse, and to reduce interaction between stages.

U108 provides regulated 5 volts for use by the binary divider, U105. C105 provides filtering and improved transient response.

±28 Volts DC come to the main integrator PC Board from a small separate power supply assembly . ±28 volts is used to drive the power stage of the integrator output and also to supply the ±12V regulated and +5 volt regulated supply.

4.5 LIMIT SWITCH

4.5.1 General Description

The limit switch controller is a factory installed option available in either a single or dual channel recorder (single channel 11-6103-01, dual channel 11-6103-02). Each channel control provides two independent switch set points at any desired position on the chart. The limit switch receives its power from the drive amplifier.

4.5.2 Circuit Description (Figure 8-23)

When the pen is positioned at a desired set point, a specific voltage is applied to two noninverting inputs of operational amplifiers, U101 and U102. Position feedback voltage is either positive or negative with respect to the upscale or downscale trip voltages. For example, if the positive feedback is two volts and the voltage set by the "downscale" control is plus one volt, the output of operational amplifier U101 is approximately 13 volts. This action causes Q101 to turn on, energizing relay K101. When relay K101 is energized, it causes light emitting diode CR-105 (panel lamp) to illuminate, indicating a trip condition. Input signal changes cause the output of the operational amplifier U101 to be - 6 volts. This allows Q101 to turn off, de-energizing relay K101 and extinguishing CR105 (down scale "on" lamp).

Operational amplifier U102 and relay switching transistor Q102 perform identical functions as U101 and Q101, with the exception that input conditions are opposite. This is necessary to energize relay K101 with down scale (negative) signals and K102 with up scale (positive) signals. Hysteresis prevents oscillation with very slow rates of change about the relay trip point. Relay contacts are connected to the recorder rear barrier strips.

4.6 INPUT SIGNAL COUPLER

4.6.1 General Description

The input signal coupler (13-4715-08) is designed to be used with a single or dual channel 110 strip chart recorder. This module is installed in the preamplifier enclosure of the recorder. It provides pen positioning and adjustable full scale ranges from 1 volt full scale to 100 volts full scale.

4.6.2 Circuit Description (Figure 8-14)

The input circuit of the pen drive amplifier is an inverting operational amplifier whose function is signal limiting and voltage gain.

The amplifier's summing resistor 108 is 10K ohms and the full scale input voltage is one volt. Resistors added to the summing resistor provide the signal coupler with various increasing full scale voltages up to 100 volts. Full scale voltages are internally selected by inserting a pin jack into the various recepticals on the printed circuit board.

As the full scale voltage increment increases, the input resistance rate (being added to the summing resistor) is 10K ohms per volt. At 100 volts full scale, the input impedance is one megohm.

4.6.3 Front Panel OFFSET Control

Plus and minus 6 volt dc reference voltages are applied to potentiometer R108 with the wiper voltage applied to the drive amplifier via pen position summing resistor R218 (drive amplifier schematic 286364). This enables the user to position the pen anywhere on the chart. Capacitors C101 and C102 filter and decouple the ±6 volt dc reference lines from the preamplifier.

4.6.4 Front Panel TRIM control

This potentiometer adjusts any full-scale sensitivity except the 1-volt range. It is in series with the internal range selection resistors and may be used to compensate for any resistor tolerance build-up. Proper setting of the TRIM control in the range being used results in precise calibration and maximum accuracy.

4.7 FIXED SPAN PREAMPLIFIER

4.7.1 General Description

The fixed span dc preamplifier (13-4715-07) is designed to be used with a single or dual channel 110 strip chart recorder. A block diagram of the preamplifier is illustrated in Figure 4-6. The preamplifier is powered from the drive amplifier power supply in the strip chart recorder. High accuracy at low signal levels is achieved by the use

of a chopper amplifier (U101) which corrects for errors caused by input voltage and current drifts. A front panel OFFSET control (R106) allows the user to position the pen (zero-volt) anywhere on the chart. The input circuit is single ended, floating and guarded, which permits the preamplifier to be operated up to 220 volts DC or peak AC off ground at any sensitivity. The input impedance at sensitivities from 1 millivolt full scale to 100 millivolts full scale is potentiometric and 1 megohm input impedance at sensitivities from 200 millivolts to 100 volts full scale. This high input impedance prevents measurement errors frequently caused by loading the signal source.

Gain modules (11-4601-xx) plug into the preamplifier front panel for rapid full scale span changes. Table 4-2 lists the gain module plug-in cards including input voltage for full scale output.

MODEL NO.	INPUT F.S. VOLTAGE
11-4601-01	.001 volt
11-4601-02	.002 volt
11-4601-03	.005 volt
11-4601-04	.010 volt
11-4601-05	.020 volt
11-4601-06	.050 volt
11-4601-07	0.1 volt
11-4601-08	0.2 volt
11-4601-09	0.5 volt
11-4601-10	1.0 volt
11-4601-11	2.0 volt
11-4601-12	5.0 volt
11-4601-13	10.0 volt
11-4601-14	20.0 volt
11-4601-15	50.0 volt
11-4601-16	100.0 volt

TABLE 4-2 FIXED SPAN GAIN MODULES



FIGURE 4-6 FIXED SPAN PREAMPLIFIER BLOCK DIAGRAM

4.7.2 Circuit Description (Figure 4-7)

1. Input Circuit

   Capacitor C201 on each plug-in gain module is for frequency compensation. Resistor R203 is in series with R101 (on main amplifier board) and is used in conjunction with zener diodes CR101 and CR102 for over voltage protection.

2. Amplifier Assembly

   Gain modules plug into J101, which is a special shorting card edge connector. An input stabilization, gain, and frequency compensation network is made up of R103, R105, and C104. This circuit prevents instability in U101 when a gain module card is removed (when changing full scale sensitivities). U101 is a noninverting chopper operational amplifier which corrects errors caused by input offset voltage and current drifts.

3. Decoupling Network and Offset Balance

   R108, C102, R107, and C103 provide low frequency decoupling of U101 from the power supply in the drive amplifier. R104 is a factory adjust offset balance adjustment.

4. Front Panel OFFSET Control

   Plus and minus 6 volt dc reference voltages are applied to potentiometer R106 with the wiper voltage applied to the drive amplifier via pen position summing resistor R218 (drive amplifier schematic 286364). This enables the user to position the pen anywhere on the chart. Capacitors C105 and C106 filter and decouple the ±6 volt dc reference lines from the preamplifier.



FIGURE 4-7 FIXED SPAN THEORY OF OPERATION DIAGRAM

4.8 MULTI SPAN PREAMPLIFIER

4.8.1 General Description

The Multi Span DC Preamplifier (13-4715-06) is designed to be used with a single or dual channel 110 strip chart recorder. The preamplifier is a high precision, high gain preamplifier which uses a chopper amplifier to correct errors introduced by the input offset voltage and current drifts. It is powered from the drive amplifier power supply in the recorder, thus eliminating power supply noise pickup and improving reliability. A calibrated zero OFFSET provides offset up to plus and minus ten times the indicated full scale sensitivity up to the maximum safe input voltage. A calibrated reading, with a resolution of one part per thousand, is provided. This allows the static portion of a complex incoming signal to be offset a known amount and the remaining portion to be displayed for more detailed evaluation.

The input circuit is floating and guarded, which permits this amplifier to be operated up to 220 volts DC or peak AC off ground at any sensitivity. It can be used with signal sources that are grounded, floating, or driven offground without experiencing "ground loops," damaged equipment, or problems normally associated with grounded input circuits.

The input is floating and guarded and provides a potentiometric input impedance in the millivolt mode and a 1-megohm input impedance in the volt mode. This high input impedance prevents measurement errors frequently caused by "loading" the signal source.

Twenty factory-set, fixed gain measurement ranges are provided, plus a variable SPAN control which increases the gain of the amplifier by three times. This permits operation at any point between the fixed gain ranges. A front panel step RESPONSE control S102-A is provided to eliminate unwanted noise while preserving the desired signal. This allows the rise time to be changed from 0.25 second full scale maximum to 0.5, 1 or 2 seconds full scale.

A block diagram of the multi span preamplifier is illustrated in Figure 4-8. The preamplifier consists of the following circuitry: input divider network (S102-B), chopper operational amplifier U101 (with gain ranging network R110), active filter stage (U102), inverter stage (U103), and an offset/output stage (U104).



FIGURE 4-8 MULTI SPAN PREAMPLIFIER BLOCK DIAGRAM

4.8.2 Circuit Description (4-9)

In the "volts" mode setting, resistors R101 and R104 provide a 200:1 division ratio with a one megohm input. For example, when the SPAN switch (S101) is in the ".1" position the gain is 2000. The gain formula and simplified circuit is illustrated in Figure 4-10. The full scale voltage (.1 volt) is 500 microvolts after the input divider (R101 and R104). After amplification, the input voltage is increased to one volt. When R110 (variable gain control) is rotated maximum clockwise, the gain is increased by a factor of 2.66. This available gain change enables the user to obtain any gain between the 1, 2, and 5 span ratios.

Diodes CR101 and CR102 protect the input circuitry of U101 against over voltage. R108 is a course input offset balance and R107 is a fine balance adjustment accessible from the front panel.

In "millivolts" mode, the input divider is out of the circuit and the R_f term in the gain equation is increased by 80K ohms. Gain in the .1 millivolt span position is 9999.1 or 1000. Note that R102 (5K ohms) is switched into the circuit as R104 is switched out, thus keeping the offset shift (due to changing bias current) to a minimum.

Capacitors C104 through C107 are frequency compensation capacitors which keep the -3 DB point approximately between 10 and 18 Hz.

The filter stage (U102) has a gain of one and provides selectable full scale responses.

The U103 stage functions as an inverter so that the overall amplifier is noninverting.

The offset/output stage (U104) operates at a gain of 1.666. Resistors R130 and R131 are a 1.666:1 divider. U104 operates as a difference amplifier. R201 is a ten turn potentiometer which may be set to cancel-out up to ten full scales of fixed dc offset. R135 is adjustable to obtain "zero" pen positioning with a 10X full scale input, when R201 is in the "10.0" dial setting.



FIGURE 4-9 MULTI SPAN THEORY OF OPERATION DIAGRAM

$$E_o = E_s \left(\frac{1 + R_f}{R_i} \right)$$

$$\text{GAIN} = \frac{1 + R_f}{R_i}$$

$$\text{GAIN} = \frac{1 + 19990}{10}$$

$$\text{GAIN} = \frac{19991}{10}$$

GAIN = 1999.1 or 2000



FIGURE 4-10 GAIN FORMULA

SECTION V

TROUBLESHOOTING

5.1 GENERAL

This section contains a troubleshooting table to assist the operator/serviceman in locating malfunctions that may occur during normal operation of the recorder.

5.2 TROUBLESHOOTING GUIDE

MALFUNCTION	CAUSE	REMEDY
1. Recorder inoperative	a. Main power not connected to source	a. Connect power to source
	b. POWER on-off switch in "off" position	b. Switch to "on" position
	c. Blown fuse	c. Replace fuse
	d. Open interlock	
	(1) Paper supply exhausted	(1) Install new roll
	(2) Paper magazine not engaged or adjusted properly.	(2) Engage properly
	(3) Chart paper wedged upward and incontact with end-of-chart sensor	(3) Remove writing table and manually roll chart forward about one inch
	e. Defective interlock circuit	e. Repair and/or replace
	f. Defective "on-off" switch	f. Repair and/or replace
2. Chart paper does not drive.	a. POWER switch in "off" position	a. Switch to "on" position
	b. CHART switch in STOP position	b. Switch to "on" position
	c. CHART SPEED switch in R (remote) position with no external pulse source applied	c. Apply drive pulse from external source.
	d. Remote Chart Drive Circuit is open	d. Replace jumper between pins 3 & 4 on rear panel terminal strip Fig. 3-2
	e. Paper magazine improperly engaged	Engage properly and reset interlock
	f. Defective interlock circuit	f. Repair and/or replace

MALFUNCTION	CAUSE	REMEDY
	g. Defective transmission and/or drive belts	g. Replace
	h. Defective drive motor	h. Replace
3. Chart paper speed is not as indicated by chart speed switch, or chart speed does not change as CHART SPEED switch is changed	a. Incorrect line voltage and/or frequency	a. Check for correct line voltage and frequency
	b. Defective CHART SPEED selector switch	b. Repair and/or replace
	c. Defective motor control circuit	c. Repair and/or replace
4. Pen will not travel on line	a. Improper track alignment	a. Re-align track
5. Pen does not move with input signal applied (all chart drive functions operate)	a. Improper input connections	a. Check input connections
	b. Zero OFFSET control is set in incorrect position	b. Disconnect or turn "OFF" input signal & reset zero offset control
	c. Defective signal conditioners	c. Replace and/or repair
	d. Defective drive amplifier	d. Replace and/or repair
	e. Defective cabling, and/or connections	e. Replace and/or repair
6. Paper not re-winding on take-up roll	a. Magazine not engaged properly	a. Engage properly
	b. Take-up roll improperly installed	b. Install properly
	c. Tension adjusted improperly	c. Adjust tension
7. Paper tears through sprockets when chart drive actuated	a. Chart paper mis-aligned on take-up roll or supply roll core	a. Adjust paper alignment - make sure supply roll is not "telescoped"
	b. Sprocket rollers binding	b. Free rollers CAUTION: IT IS NOT ADVISABLE TO USE LUBRICANT ON ANY OF THE ROLLERS OR DRIVE ASSEMBLIES.
	c. Chart takeup clutch too tight	c. Readjust to 5 inches on torque

SECTION VI

MAINTENANCE

6.1 GENERAL

This section contains preventive and corrective maintenance procedures that can be performed by the operator. However, for major maintenance requirements, contact the nearest Gould Service Representative.

6.2 COVER ASSEMBLY

6.2.1 Removal

a. Turn recorder "off" and disconnect ac power cord from source.

b. Lay recorder on side, remove four screws from bottom of cover assembly and return recorder to upright position.

c. Carefully slide cover assembly forward from recorder.

6.2.2 Installation

a. Carefully slide recorder into cover assembly from the rear.

b. Lay recorder on side and secure cover assembly to recorder with four screws removed in paragraph 6.2a.

c. Return recorder to its upright position.

d. Connect ac power cord to correct power source.

6.3 CHART PAPER INSTALLATION

a. To remove the writing table, grasp both sides of the "pull bar" and lift upward to the 90° position, then pull outward. (see Figure 6-1).

b. Place the writing table (viewing side down) on a flat surface.

c. Remove a new roll of writing paper from it's container. Remove the spring loaded "bushing assembly" (684845) from the used paper core and insert it into the new paper roll (see Figure 6-2).

d. Insert one end of the writing paper roll into the paper "supply hub" aligning the grooves on the paper supply core to the hub supply roll (see Figure 6-3).

NOTE: The small "bushing assembly" (684845) is always used on the supply roll.

e. Insert the other end of the paper roll into the groove located in the left hand side plate (see Figure 6-2).

f. Pull paper under the "drive roller" and over the "pressure roller" (Figure 6-4). Tape the leading edge of the writing paper to the "internal take-up core" illustrated in Figure 6-5.

g. Insert the writing table into the recorder.



FIGURE 6-1 REMOVING WRITING TABLE



FIGURE 6-2 WRITING TABLE ASSEMBLY



FIGURE 6-3 GROOVES IN PAPER SUPPLY CORE



FIGURE 6-4 INSTALLATION DIAGRAM



FIGURE 6-5 INTERNAL TAKE-UP

SECTION VII

CALIBRATION

7.1 GENERAL

The Gould 110 strip chart recorder is calibrated at the factory to insure optimum performance. However, calibration may be required when parts are replaced. This section describes and illustrates the procedures necessary to calibrate the recorder, including preamplifiers.

NOTE: Calibration should be performed by qualified individuals.

7.1.1 Test Equipment Required

The following is a list of recommended test equipment for calibration of the recorder.

Oscillograph (MK 280 or equivalent).
Differential voltmeter (Fluke model 8300A, or equivalent).
DC calibration source (Digitec model 311, or equivalent, Rs = 1 ohm or less).
Function generator (Wavetek model 110, or equivalent).
DC responding RMS voltmeter or thermocouple AC voltmeter (Sensitive Research Instruments model USP or equivalent).
Variac voltmeter (voltmeter accuracy ±2%).
Synchronized timing generator
Extension board (Gould 886604)
Frequency Counter .01% accurate. Hewlett Packard model 5245L Electronic Counter with model 5262A time interval unit or equivalent. (used for integrator option only)
Optional: MK 280 recorder or equivalent. (used for integrator option only)

7.1.2 Preliminary Setup

a. Remove recorder from case and attach to proper power line.

b. Insert main power plug into Variac. Do not turn unit on. Connect ac voltmeter to Variac output.

WARNING: EXPOSED AC LINE VOLTAGE WILL BE PRESENT AT VARIOUS POINTS ON THE UNIT.

c. Remove drive amplifier printed circuit board from the rear of mainframe. Insert extender board (886604) into the drive amplifier location and plug the drive amplifier into the extender board.

d. Short the input terminals to the drive amplifier.

e. Rotate R117 (PEN HEAT ADJUST) counterclockwise (see Figure 7-4).

f. Rotate outer "TRACE DENSITY" knob (located on front panel) counterclockwise. Rotate inner "trace balance" control clockwise. The recorder is ready for calibration checkout.

7.2 INPUT SIGNAL COUPLER (13-4715-08)

7.2.1 Calibration Checkout

a. Insert span pin jack into the TWO VOLT FULL SCALE recepticle. Insert signal coupler into strip chart mainframe. Turn POWER switch on (CHART switch remains off in this step). Allow recorder to warm up for 15 minutes.

b. Connect voltage calibrator to signal coupler input as follows: positive lead of calibrator to HI input and negative lead to LOW input.

c. Set calibration voltage to 0.000. Turn the recorder CHART switch on. Set CHART SPEED to a convenient speed greater than 30 in/hr.

d. Adjust TRACE DENSITY control so that line is visible.

e. Adjust pen position control (R220) on the drive amplifier board (886046) until the trace is on the righthand zero line (if integrator paper 11-2915-12 is used, the zero line is three minor divisions to left of first line).

f. Apply a full scale input signal to the coupler (2.0 volt ±.01%). The pen should deflect 100 (±.25) divisions to the left.

g. Depress CHART switch to stop position and remove coupler. Insert span pin jack into the 100 VOLTS FULL SCALE recepticle.

h. Set calibration voltage to 0.000. Adjust OFFSET control until pen is at the zero chart line.

j. Apply 100 volts (±.01%) to the coupler. Pen should deflect approximately 100 divisions to the left.

k. Adjust TRIM control to obtain exactly 100 divisions of deflection.

l. Remove the 100 volt input calibration signal from the recorder. Pen should return to the zero volt position on the chart.

7.2.2 Offset Operation Checkout

a. Insert span pin jack into the 20 VOLT FULL SCALE recepticle of the amplifier.

b. Insert signal coupler into the recorder mainframe.

c. Switch POWER and CHART controls to the ON position.

d. Set CHART SPEED control to 60 in/hr.

e. Rotate the OFFSET control, moving the pen over its entire range from the left to the righthand limit. (Allow the pen to remain at the righthand limit.)

7.2.3 Full Scale Span Calibration

a. Remove signal coupler and insert span pin jack into the 100 VOLT FULL SCALE recepticle.

b. Insert signal coupler into the recorder mainframe.

c. Connect voltage calibrator to the signal coupler input as follows: positive lead to HI input of coupler and negative lead to LOW input.

d. Apply 100 volts (±.01%) to the coupler input. The pen should deflect approximately 100 divisions.

e. Adjust the TRIM control to obtain exactly 100 divisions of deflection.

f. Remove the 100 volt input calibration signal from the coupler. Pen should return to the zero volt position on the chart.

g. Check the remainder of the full scale sensitivities using the same method described in this subsection.

NOTE: 1 volt position not affected by Trim R-101. Also, Trim R-101 must be adjusted for any given range to give best accuracy.

7.3 FIXED SPAN PREAMPLIFIER (13-4715-07)

7.3.1 Preamplifier Balance

NOTE: Allow the preamplifier to warm up 30 minutes while in the recorder mainframe before adjusting the preamplifier balance potentiometer (R-104)

a. Short the front or rear input terminals to the preamplifier. (This may be accomplished by using a piece of copper wire).

b. Plug the one millivolt gain module (11-4601-01) into the slot in the front of the preamplifier.

c. Connect the differential voltmeter to the preamplifier output terminals (positive lead to pin D terminal and negative lead to pin G terminal). See Figure 7-1.

d. Adjust R-104 for zero volts (±1 millivolt).

7.3.2 Gain Accuracy

a. Insert the one millivolt full scale gain module (11-4601-01) into the slot located in the front of the preamplifier.

b. Connect the differential voltmeter to the preamplifier output terminals (positive lead to pin D terminal and negative lead to pin G terminal).

c. Connect the calibrated voltage source to the preamplifier input (positive lead to HI terminal and negative lead to LO terminal). Set calibration voltage to 0.000 (differential voltmeter should read zero volts).

d. Apply full scale voltages to the preamplifier input as follows:

INPUT VOLTAGE	PLUG-IN GAIN MODULE	FULL-SCALE OUTPUT VOLTAGE
0.001 ± .02%	11-4601-01	1 volt ± .25%
.01 ± .02%	11-4601-04	1 volt ± .25%
.1 ± .02%	11-4601-07	1 volt ± .25%
1. ± .02%	11-4601-10	1 volt ± .25%
10. ± .02%	11-4601-13	1 volt ± .25%
100. ± .02%	11-4601-16	1 volt ± .25%

e. Direct current voltage offset shift (from range to range) should not exceed ±2.5mv.

f. Removing gain module does not cause preamplifier to become unstable or the output to drift off scale.

7.3.3 Response Check

a. Connect square wave generator to preamplifier input. Set peak-to-peak amplitude of the input square wave to the full scale gain span voltage.

b. Connect oscillograph to the preamplifier output. Display square wave so that the rise time is easily read by using a high chart speed. (A convenient chart speed is 100mm/sec for short bursts, 10 msec/mm.)

c. Measure the rise time of the preamplifier with the following gain modules:

MODEL NUMBER	DESCRIPTION
11-4601-14	20V
11-4601-08	2V
11-4601-05	0.2V

(Rise time should be no greater than 0.1 second, measured from 1% to 99% of full scale, 50 divisions).

7.3.4 Maximum Safe Input

a. Insert 100 mv gain module (11-4601-07) into the preamplifier. Apply +15 vdc to the preamplifier input terminals.

b. Measure the dc voltage across diodes CR101 and CR102 (see Figure 7-1). The voltage must not exceed 8.8 vdc.

c. Apply -15 vdc to the preamplifier input terminals. Repeat step 2.

d. Repeat steps 1 and 2 using 220 vdc input.

NOTE: The two 5K, 4 watt resistors located on the gain module and main preamplifier card (see Figure 7-1) become hot if the voltage remains on.

7.3.5 Common Mode Rejection

a. Connect a 1000 ohm resistor between the HIGH and LOW inputs to the preamplifier.

b. Insert a 1 MV FULL SCALE gain module (11-4601-01) into the preamplifier.



FIGURE 7-1 FIXED SPAN PREAMPLIFIER (13-4715-07)

c. Connect preamplifier output to oscillograph. Set sens/div to 0.001 volt.

d. Apply a 10 volt peak-to-peak (60Hz) sine wave to the preamplifiers LOW and GD input, with respect to the preamplifier housing. Secure front panel to preamplifier housing with a screw. Connect printed circuit connector terminal "H" to the preamplifier housing (see Figure 7-1).

NOTE: Use the ac line voltage into a variac connected to an isolation transformer as the common mode drive voltage source.

e. The output peak-to-peak voltage should not exceed 0.010 volts peak-to-peak or 10 divisions of the oscillograph when it is set to 1 mv/div sensitivity.

7.3.6 Noise Check

a. Insert a 1MV FULL SCALE gain module (11-4601-01) into the preamplifier. Short the three input terminals (HI, LO, and GD) together.

b. Insert preamplifier into recorder mainframe. Operate strip chart recorder at 8 in/min and position the trace between two grid lines.

c. Noise should be one division (peak-to-peak) or less, on a single channel recorder (15-4318-xx).

7.4 MULTI SPAN PREAMPLIFIER (13-4715-06)

7.4.1 System Calibration

NOTE: When the Multi Span Preamplifier is installed in a Gould 110 Recorder perform the following:

a. Set POWER and CHART switches on.
b. Set CHART SPEED at 60 inches per hour.
c. Set SPAN knob to OFF.
d. Set OFFSET switch to OFF.
e. Set RESPONSE dial to FULL.
f. Adjust pen position potentiometer R220, located on the drive amplifier board 886046 (Figure 7-3) until the pen is on the zero grid line.
g. Allow preamplifier to warm up 30 minutes.

7.4.2 Chopper Amplifier Balance

a. Short the three input terminals (HI, LO, and GD) together to the drive amplifier.

b. Set RESPONSE knob to .5 SEC position.

c. Set inner RESPONSE knob to MV (millivolts).

d. Connect a differential voltmeter to the output of the preamplifier (see Figure 7-2).

e. Rotate SPAN knob clockwise to .1 position.

f. Rotate variable SPAN control counterclockwise until it clicks.

g. Adjust the chopper amplifier course balance (R108) to approximately +1 volt output on the differential voltmeter.

h. Rotate fine balance adjust (R107) clockwise until the differential voltmeter voltage stops decreasing. Record the voltage. Rotate R107 clockwise until the voltage stops increasing and record the voltage. Add the lower reading to the higher reading, and divide the result by 2. Rotate R107 counterclockwise until the differential voltmeter indicates this number. The balance potentiometer is now in the center of its range.

j. Rotate chopper amplifier course balance (R108) until the output is less than 100 millivolts. Rotate the variable gain control from maximum counterclockwise to maximum clockwise and adjust R108 for less than 10 millivolts change. (1 division on strip chart.)

7.4.3 Offset Potentiometer

a. Connect a differential voltmeter to the output of the preamplifier (pins D and G). See Figure 7-2.

b. Rotate SPAN control to 10 and volts/millivolts knob to VOLTS. Set OFFSET toggle switch to OFF position. Set RESPONSE to FULL position. Rotate variable SPAN full counterclockwise until it clicks.

c. Connect calibrated voltage source to the input terminals of the preamplifier (plus lead to HI,



FIGURE 7-2 MULTI SPAN PREAMPLIFIER (13-4715-06)

negative lead to LOW). Set the voltage source output dials to 0.000. Record offset as read on voltmeter.

d. Apply 100 volts dc (+0.01%) to preamplifier input. Set the OFFSET polarity switch to "+". Set OFFSET vernier dial to 10.0.

e. Adjust potentiometer R135 to within ±2mv of reading in 7.4.3c, above.

7.4.4 Response Check

a. Connect a square wave generator to the preamplifier input.

b. Set peak-to-peak amplitude of input square wave to SPAN dial settings e.g., 10 volt peak-to-peak square wave for 10 volt full scale span, etc.

c. Connect preamplifier output to an oscillograph.

d. Set square wave generator to 1Hz. Set RESPONSE knob to FULL position. Set OFFSET toggle switch to the OFF position. Set variable SPAN control to X1. (Turn full counterclockwise until gain control clicks.)

e. Adjust the square wave amplitude to get full scale deflection on the oscillograph (1 volt peak-to-peak). A convenient chart speed is 100 mm/sec for short bursts (1 mm of chart equals 10 milliseconds).

f. Rise time in the full response setting should be less than 50 milliseconds.

g. Lower the square wave frequency to 0.25Hz.

h. Measure rise time in the .5, 1, and 2 second RESPONSE mode settings. Measured rise time should be within ±20% of indicated settings.

7.4.5 Noise Check

a. Short the input terminals to the preamplifier (connect HI, LO, and GD together).

b. Set RESPONSE switch to FULL.

c. Set VOLTS/MV switch (concentric with the RESPONSE switch) to MV.

d. Set SPAN switch to .1.

e. Set OFFSET toggle switch polarity to "–".

f. Insert preamplifier into the strip chart mainframe and set CHART SPEED at "8 in/min".

g. Adjust OFFSET vernier to position the pen trace between two grid lines.

h. Noise should be one division (.010V) or less (peak-to-peak).

7.4.6 Balance Check

a. POWER and CHART switches on.

b. RESPONSE in 1 sec. position.

c. CHART SPEED in 60 inches/hour position.

d. Turn SPAN switch maximum clockwise.

e. Volts-millivolts switch to mv position.

f. Rotate variable SPAN knob from maximum counterclockwise (detent position) to maximum clockwise end.

g. Pen can deflect a total of 2 divisions (minor divisions).

h. Switch volts-millivolts switch to VOLTS.

j. Pen can deflect a total of .3 divisions.

k. Adjust fine balance pot (hole in front panel) so that when step "f" above is performed there is less than 2 div of pen movement in VOLTS mode and in millivolts mode.

7.4.7 System Gain Check

a. POWER on.

b. CHART off.

c. Drive amp plugged into EXTENDER card.

d. Set Multi Span Preamplifier SPAN switch to OFF.

e. Connect calibrated voltage source to HI & LO terminals of preamplifier.

f. Put RESPONSE switch in FULL.

g. Put OFFSET switch in OFF.

h. Switch CHART switch on and CHART SPEED to 1 inch/minute. SPAN switch to 1 volt.

j. Set voltage source dials to 0.000 and switch CHART switch on. Pen should be at the zero grid line within ±.1 division.

k. Switch calibrated voltage source to 1.0 volt ±.02%.

l. Pen should deflect 100 div ±.25 div.

m. Set source to .5 volts ±.02%.

n. Pen should deflect 50 div ±.25 div.

7.5 DRIVE AMPLIFIER (886046)

7.5.1 Preliminary Setup

a. Remove drive amplifier and insert extender board (886604).

b. Plug drive amplifier into the extender board.

c. Allow a thirty minute warm up period before preforming the following tests on the drive amplifier.

7.5.2 Reference Supply

a. Connect a differential voltmeter to the drive amplifier (negative lead to TP-2 and positive lead to TP-1). See Figure 7-3 for the location of test points.

b. CHART switch remains in the OFF position.

c. Adjust R-212 for +12.000 volts (±0.005 vdc).

d. Reposition the negative lead of the voltmeter from TP-2 to TP-3.

e. Adjust R-215 for +6.000 volts (±0.003 vdc).

f. Disconnect test leads.

7.5.3 Limiter Position and Span Adjustment

a. Switch POWER and CHART controls to the ON position without the preamplifier plugged into the recorder.

b. Apply a dc voltage to the drive amplifier input (pin B), so that the writing pen is to the right electrical limit. See Figure 7-3. Adjust R-229 until the pen is on the right hand electric limit line (½ division to the left of chart edge).

c. Apply a dc voltage to the offset input (pin A) of the drive amplifier to position the pen to the center of the chart

d. Apply a less than full scale 0.5Hz sine wave to the drive amplifier input (pin B) and slowly increase the amplitude until the peaks go into the limiters and the signal is approximately 2x (full scale).

e. Adjust R-229 until the trace is centered on the chart.

f. Adjust R-226 until the peaks of the trace are on the limit lines. (A slight readjustment of R-229 and R-226 may be necessary to accurately position the trace on the limit lines.

7.5.4 Pen Position

a. Short the input terminals to the drive amplifier (see Figure 7-3).

b. Switch POWER and CHART controls to the ON position.

c. Adjust R220 (Figure 7-3) until the pen is on the zero grid line.

7.5.5 Span

a. Position writing pen on the zero grid line by shorting the input (pin B) of the drive amplifier to ground and adjusting pen position potentiometer R220 (see Figure 7-3).

b. Apply a positive one volt (±0.02%) signal to the drive amplifier input.

c. Measure the amount of error on the chart and adjust R254 until 50% of the error is corrected.



	TEST POINTS		PINS
1	+6V.DC REF	A	PEN POSITION
2	-6V.DC REF	B	INPUT SIGNAL
3	COMMON	C	COMMON
4	+15 V.DC	D	-15V
5	-15V.DC	E	+15V
6	POSITION FEEDBACK	F	+6
7	BUFFERED POSITIVE FEEDBACK	H	-6
8	POSITIVE FEEDBACK	J	-6
9	VELOCITY (DAMPING)	K	+6
10	LIMITER	L	POSITIVE FEEDBACK
11	SUMMING AMPLIFIER OUTPUT		

FIGURE 7-3 DRIVE AMPLIFIER BOARD (886046)

d. Remove the calibrate signal or turn calibrator dials to 0.000 volts.

e. Short the input on the drive amplifier and readjust R220 until the pen is on the zero grid line.

f. Repeat steps 2 through 4 until the position of the pen is exactly on the zero and full scale grid lines when the shorted and full scale (1 volt) input signals are applied.

7.5.6 Damping

a. Set CHART SPEED knob to 2in/min.

b. Adjust function generator output to 0.5 Hz square wave.

c. Connect the signal from the generator to the input terminals of the drive amplifier. (If the preamplifier is a multi span 13-4715-06, switch RESPONSE to FULL).

d. Apply a dc voltage (approximately 0.5 volts) to the offset input (pin A) of the drive amplifier so that the writing pen is centered on the chart. See Figure 7-3.

e. Apply a full scale square wave to the drive amplifier.

f. Adjust R224 until the overshoot is eliminated.

NOTE: Line voltage will affect the calibration. Perform the adjustment at nominal line voltage.

7.5.7 End of Chart Sensor

a. Place a piece of cardboard over the mainframe to simulate the light shielding effect of the unit case on the sensor.

b. Rotate R101 (end of chart sensitivity adjust) full counterclockwise. See Figure 7-4.

c. Switch POWER and CHART controls to the ON position.

d. Adjust R101 slightly beyond the point where relay K101 energizes and the chart switch indicator lamp illuminates.

NOTE: When removing writing table, the chart switch indicator lamp is extinguished. It illuminates when writing table is inserted (providing the chart paper is flat against the drive roll). This condition indicates proper operation/adjustment of the end of chart sensor.

7.5.8 Pen Heat

a. Install writing table in mainframe. Depress CHART switch to STOP position.

b. Adjust R117 maximim counterclockwise.

c. Switch POWER control to ON position.

d. Connect low COMMON lead of true RMS meter to TP-4 (**WARNING - LINE VOLTAGE ON NEARBY PINS**) and the high PLUS lead to TP-5 of the main control board. See Figure 7-4.

e. Adjust front panel TRACE DENSITY controls for maximum clockwise rotation.

f. Adjust the Variac to 115 volts and switch CHART control to the ON position. Set CHART SPEED at 2in/min.

g. Adjust R117 for 5.00 volts (±0.05 vac RMS).

h. Adjust TRACE DENSITY knob for a clear and distinct trace.

j. Disconnect test leads.

7.5.9 Chart Speed Check

a. Switch POWER control the ON position.

b. Switch CHART control to the START position.

c. Set CHART SPEED knob at 1 in/hr. (or 2.5 cm/hr. for metric units).

d. Check proper operation by observing the sweep second hand of a watch. The pulse drive motor output can be felt by placing a finger on the small pulley. Belt pulses occur at a rate of 0.25Hz, or one pulse every four seconds for standard (English) chart speeds. Metric (50Hz) chart speeds occur at 0.21Hz rate, or one pulse every 4.8 seconds.

e. Connect a timing generator to one analog channel. Set generator amplitude for a convenient counting period. Set generator output fre-



FIGURE 7-4 RECORDER CONTROL ASSEMBLY

quency to 0.1Hz (±.25%).

f. Set recorder CHART SPEED knob to 8 in/min. for standard (English) units. On metric units, set the CHART SPEED knob to 20 cm/min.

g. Count for six periods and measure the length of the chart. For standard chart speeds, the length is eight inches (±1%). Metric length is 20 cm, ±1%.

7.5.10 Writing Quality

a. Plug in a calibrated preamplifier.

b. Set CHART SPEED knob to 8 in/min.

c. Connect a signal generator to the preamplifier inputs.

d. Apply a 0.05 Hz triangle wave from the signal generator to the preamplifier.

e. Coordinate the preamplifier SPAN and OFFSET controls with the input signal for a full scale recording.

f. Adjust the DENSITY trim (inner, smaller knob of the TRACE DENSITY control) maximum clockwise.

g. Adjust the TRACE DENSITY control for a clear readable trace. Trace must be uniformly dense and distinct for 100 divisions.

h. Adjust the DENSITY trim knob counterclockwise, the lower pen trace density should decrease. In dual channel units this control is used to lower the density of the lower pen trace, thereby increasing the readability and eliminating confusion as to which trace is the lower channel.

7.5.11 External Pulse Drive Test

a. Connect a square wave generator to the PULSE INPUT on the rear panel of the recorder.

b. Apply a square wave signal to the recorder (greater than 2 and less than 30 volts, peak-to-peak). Adjust frequency to 120Hz (±1Hz).

c. Set CHART SPEED knob on the recorder front panel to R (maximum clockwise).

d. Place POWER and CHART switches to the ON position. The chart speed is now controlled by the frequency of the generator. The 120Hz input is the maximum frequency and provides the fastest chart speed of 8 in/min (or 20 cm/min for metric units). Chart speed is linear with respect to external input pulse frequency (i.e., 120Hz yields 8in/min; 60Hz yields 4 in/min,etc.).

7.6 LIMIT SWITCH (Figure 7-5)

The limit switch set point controller is a factory installed option available in either a single or dual channel recorder. Each channel control provides two independent switch set points at any desired position on the chart. Each set point is provided with a visual indicator located behind the writing table. To set a limit switch, perform the following:

a. Remove writing table.

b. Set channel to upper and lower limits desired using the OFFSET control located on the preamplifier.

c. Adjust limit control switches until lamp is illuminated for required limit settings for each channel.


Limit Switch Indicators
(provide two independent out-of-limit indicators for each analog channel)
Lower Channel Controls
(provides two independent limit switch set points for the lower analog channel)
LOWER
UPPER
LEFT
RIGHT
LEFT
RIGHT
Upper Channel Controls
(provides two independent limit switch set points for the upper analog channel

FIGURE 7-5 LIMIT SWITCH INDICATORS

7.7 CHART INTEGRATOR (11-6105-00,-01)

NOTE: Integrator calibration should be performed only after the drive amplifier has been calibrated. (See Paragraph 7.5)

7.7.1 Initial Set-Up

a. Remove integrator P.C. board from mainframe card guide.

b. Disconnect harness wire which goes to pin 14 of integrator P.C. board. (Use extraction tool on molex contact).

c. Connect pin 14 on P.C. card to the HI terminal of the voltage source. Connect the LO terminal to TP-1 of integrator P.C. board.

d. Plug 15 pin molex connector into molex strip on P.C. card. Refer to Figure 7-6 for test points and adjustment pot locations.

e. Connect + lead of vom to TP-9 and - lead to TP-1. Set F.S. sensitivity to 10V. DC.

f. Turn POWER ON.

g. Integrator pen will move to the center of its travel.

h. Turn CHART switch ON. Pen may move to either side of chart or may sweep back and forth.

j. Adjust R151 for lowest pen drift when the voltage at TP-9 is 4.5 volts (Approx).

k. Now apply 100MV for as much time as it takes to cause voltage at TP-9 to go to +.7V.

l. Adjust R112 for minimum pen drift.

7.7.2 Polarity Sense Offset Adjust (R155)

a. Locate R155 on Figure 7-6.

b. Set FULL SCALE of VOM to read approximately 12V. and connect + lead to TP-5 and - lead to TP-1.

c. Turn on POWER on mainframe.

NOTE: Strip chart mainframe should be warmed up 30 minutes before any final adjustments or checks are made. Properly adjusted preamps must be used with integrator.

d. Set signal source voltage to +100 millivolts.

e. Reverse signal source polarity.

f. TP-5 voltage should switch to opposite polarity. If it does not switch, adjust R155 until it just switches.

g. Set source voltage to 10 millivolts and reverse polarity.

h. If the voltage at TP-5 does not switch to the opposite polarity, adjust R155 until it does.

j. Repeat steps d, e, & f, above, but reduce the signal until 0.5 millivolt is reached and TP-5 is switching polarity from approximately 11 volts to -11 VDC.

NOTE: Oscillation of TP-5 voltage with critical low input voltages is possible and permitted.

7.7.3 Full Scale Time Adjustment

a. Chart switch in OFF, power switch ON. Pen will be in center of its travel with chart switch in OFF.

b. Connect electronic counter hot lead to TP-2 and the common lead to TP-1.

c. Set START & STOP dials to 1.0 volts.

d. Switch input mode switch of counter to common so the same signal is used in starting and stopping clock.

e. Set START slope to negative and STOP slope to positive.

f. Set time base so that 1000 milliseconds can be read to the nearest 0.1 milliseconds.

g. Set voltage standard to +1.000 ±.01%.

h. The electronic counter gate light will flash OFF and ON. The gate light must be ON when the voltage at TP-9 is at approximately -4.5 volts. (Q101 is OFF).

j. Adjust R-106 for 1000 milliseconds ±.5 ms.

k. Now set START slop to (+) and STOP slope to (–). The electronic counter gate light will now flash ON when the TP-9 voltage is at +.7V, (Approx), indicating Q101 is ON.

l. Adjust R-109 for 1000 milliseconds ±.5 millisecond. The upscale time and down scale time have now been preliminarilly adjusted.

m. Switch voltage source to 0.000 volts.

7.7.4 Balance Adjust (Upscale & Down Scale)

a. Turn chart switch ON.

b. With voltage source apply 100 millivolts to input until TP-9 voltage is at -4.5V.

c. Adjust R151, balance adjust on Sub-panel for less than 2 counts/min. drift.

d. Jog pen to opposite alternation so that the TP-9 voltage is at +.7V approximately.

e. Adjust R112 balance adj. on P.C. board so that there is less than 2 counts per minute drift.

NOTE: A MK 280 or equivalent will speed up this balancing process. Connect recorder across TP1 COMMON and TP-10. The initial sensitivity/div. is 500Mv. Increase sensitivity in order to SEE the drift and correct it W/O waiting for trend. Turn chart switch off.

f. Repeat Section 7.7.3, F.S. time adjustment, paragraphs g, h, j, k and l; touching up the FULL SCALE time pots.

NOTE: The balance and FULL SCALE time adjustments are interactive. If balance is not at min. F.S. alternation time will be OFF.

g. Set voltage source to 0.000.

7.7.5 Pen Centering and Span Adjustment

a. Turn power ON. Chart switch OFF.

b. If the pen is not on the center line of the integrator grid loosen set screw with allen wrench and position it there. Tighten set screw.

c. Switch voltage source to +1 volt and adjust R134 until the trace is centered on integrator grid.

d. Adjust R-149 for full scale trace. See Figure 7-6 for location of pots.

e. Leave the leads on the integrator P.C. board input.

7.7.6 Damping Adjustment

a. Set voltage source to 4 volts ±1%.

b. Adjust R143 for full scale deflection.

c. Check this adjustment by alternately applying 100MV & 4 volts signal and adjusting the damping to get constant amplitude ±2%.

7.7.7 Final Balance Adjustment

a. Disconnect all equipment test leads.

b. Reconnect harness wire which goes to pin 14 of molex strip. This connects the preamp to the integrator circuit.

c. Install integrator P.C. board in mainframe.

d. Short preamp input terminals (lower channel preamp). If the preamp is a multispan preamp 13-4715-06 be sure offset switch is in OFF. If it is a fixed gain preamp 13-4715-07 make sure that a gain module is plugged into the preamp.

e. Adjust R151 balance control for less than 2 counts/min. R151 is located on subpanel behind writing table.

f. R151 can be reached W/O removing the writing table as long as the main frame is not in a case. If the unit is cased, remove writing table and push the pushbutton next to balance pot R151. Adjust balance pot so that the integrator count is 2 counts per minute or less.

7.7.8 Baseline Zero Check

a. Set CHART SPEED to 60 in/hr or 150 cm/hr.

b. Turn CHART switch ON.

c. Observe the total number of counts per minute (each minor division of the integrator chart is worth 10 counts).

d. The total number of counts per minute should be less than 2 counts/min.

7.7.9 Accuracy Check

a. Touch up integrator balance so that the drift rate is less than ±2 counts per minute with preamp input shorted. Suggestion: Use fixed gain preamp and 1 VFS gain module.

b. Turn CHART switch ON. Switch chart speed switch to 4 inches per minute or 10 CM per minute.

c. Apply +1 volt DC ±.2 millivolt to preamp input. Connect positive voltage source lead to red HI preamp input and negative source lead to black LO.

d. There should be 6000 counts ±15 in one minute of chart. One minute of chart is 4 inches when using english model and 10 CM for the metric unit. The total count consists of the total number of FULL SCALE pen (1 inch) traverse plus the total of the partial traverses.

The following table should prove helpful:

1 Full Scale of Int. Pen	=	1 inch traverse.
1 Traverse of Pen	=	100 counts.
1 Traverse of Pen	=	10 minor division.
1 Minor Division	=	10 counts.
6 Traverses or 10 Traverses	=	1 L.H. + PIP or 1 R.H. - PIP.

NOTE: The pips occur every 600 or 1000 counts and are an aid in reduction of the chart data to a number.

e. Now with the chart speed at 4"/min. apply -1 volt ±.2MV to preamp.

f. There should be a total count of 6000 counts ±15 counts in 4 inches of chart.

g. Now with chart speed at 4"/min. or 10CM/min apply -0.1 volt ±.2MV. to preamp.

h. There should be a total count of 600 ±30 counts in one minutes worth of chart.

j. Repeat step "C" with +0.1 volt ±0.2MV. There should be 600 ±30 counts displayed.

7.7.10 Mechanical-Electrical Centering Check

a. Set chart speed to 60"/hr.

b. Apply +1 volt to preamp input. Adjust pen heat for clear distinct trace.

c. Individual triangle waves shall be centered in the 1 inch wide integrator chart band.

d. The 600 COUNT or 1000 count pips shall be clearly visible.

e. The integrator pips shall be .1 division high, MIN.

f. The integrator pips shall be on the left hand side for positive going signals.

7.7.11 Overrange Check

a. Same as 7.7.10b except slowly increase positive D.C. voltage to 4 volts ±40MV.

b. The amplitude should be one FULL SCALE (1.0 inch) ±.2 div.



FIGURE 7-6 CHART INTEGRATOR

SECTION VIII

PARTS IDENTIFICATION

8.1 GENERAL

The Gould 110 Strip Chart Recorder has been accurately calibrated and adjusted before shipment from the factory and should give long, trouble-free service. For servicing beyond the scope of the instructions contained in this manual or the technical equipment avaiable, contact your nearest Gould Service Engineer listed on the warranty card shipped with the recorder.

To assure prompt and satisfactory delivery of replacement parts, include the following with the purchase order.

1. Name, model number, and serial number of the instrument.

2. Description of the parts as listed in the manual.

3. Gould part number.

NOTE: Do not use the symbol number from the parts list for identifying desired parts on the order.

The Parts Identification section is divided into subsections illustrating the mainframe, preamplifiers, and options/accessories.

The following parts lists, exploded views, and schematic diagrams, are designed to assist in servicing and repairing the recorder.

8.2 MAINFRAME (15-4318-00, 15-4328-00)

The "mainframe" subsection contains an illustrated parts breakdown of subassemblies comprising the 110 Strip Chart Recorder (including parts lists and schematic diagrams).

8.3 PREAMPLIFIERS

The Gould 110 Strip Chart Recorder is designed to accomodate various types of preamplifiers. See paragraph 1-4 for available models. The preamplifiers are in a group (following the mainframe section) which contains an exploded view of components for each preampifier, including parts lists and schematic diagrams.

8.4 OPTIONS/ACCESSORIES

The options/accessories are in a group following the preamplifiers. This group contains an illustrated parts breakdown, including a parts list and schematic diagram for each of the options available with the Gould 110 Strip Chart Recorder. The options and accessories illustrated are as follows:

- Limit Switch (Single and Dual Channel 11-6103-01, 02)
- Chart Integrator (Single and Dual Channel 11-6105-00, -01)
- Event Marker (Left and Right Margin 11-6222-16, -17)*
- Retransmitting Potentiometer (Single and Dual Channel)

NOTE: For parts information on the left and right margin event markers see Figures 2-7 and 2-8, respectively, in the installation section.

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
RECORDER ASSEMBLY-SINGLE AND DUAL CHANNEL MODELS, 15-4318-00, 15-4328-00
FIGURE 8-1

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	884885-1	Table Assy } See Figure 8-5	
	884885-2	Table Assy (Metric) }	
2	885287-1	Recorder Subassy (Single Channel) } See Fig. 8-2	
	885287-2	Recorder Subassy (Dual Channel) }	
3	10-286044-303	Resistor, Variable	
4	265760-1	Contact, Elec.	
5	886139	Case Assy (See Fig. 8-7)	
6	116198-10	Fuse	F-301
7	1-282930-2	Pully-Zot.	
8	269945-22	Belt, Timing	
9	684933	Panel Assy - S.S.	
	686648	Panel Assy - S.S. (Metric)	
10	285652-2	Knob, Control	
11	286012-1	Switch, Toggle	
12	685102	Bezel, Switch	
13	25-106766-4	Nut, Hex	
14	285651-3	Knob, Control	



FIGURE 8-1 RECORDER ASSEMBLY (15-4318-00, 15-4328-00)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
RECORDER SUBASSEMBLY – SINGLE AND DUAL CHANNEL MODELS, 885287-1, 885287-2
FIGURE 8-2

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	.386471	Panel, Shield	
2	286320-1	Block, Clamping (Single Channel)	
3	286320-2	Block, Clamping (Dual Channel)	
4	885111-1	Chassis Assy (Single Channel) } See Fig. 8-3	
	885111-2	Chassis Assy (Dual Channel) } See Fig. 8-3	
5	11-2824-37	Stylus Assy, Lower	
6	785942	Scale Assy. S.S.	
	686298	Track Assy, Upper (Includes items 7 through 9) (Dual Channel)	
7	686299	Track, Upper	
8	485926	Board, P.C.	
9	281502-1	Contact, Elec.	
10	686281-3	Bumper	
11	282923-2608	Screw, Self-Lock	
12	1-118195-303	Washer, Plain	
13	284812	Spring, Compression	
14	686292	Carriage Assy (See Fig. 8-3A)	
15	11-2824-36	Stylus Assy, Upper (Dual Channel)	
16	885112-1	Pen Drive Assy (Single Channel) } See Fig. 8-4	
	885112-2	Pen Drive Assy (Dual Channel) } See Fig. 8-4	
17	786463-1	Panel, Rear (Single Channel)	
	786463-2	Panel, Rear (Dual Channel)	
18	886046-1	Board Assy, Drive Amp (See Fig. 8-10 & 8-11)	
19	286577-2	Cover	
20	286577-1	Cover	
21	129699	Jumper, Terminal Strip	
22	1-286155-4	Board, Terminal	TB-401
23	786465	Panel Assy, Rear Term Mtg.	
	786470	Harness Assy, Remote Chart (Includes items 24 through 27)	
24	232997-23	Strap, Retaining Cable	
25	265915-1	Contact, Elec.	
26	281502	Contact, Elec.	
27	9-281501-8	Connector	J-101-B
28	685451	Panel Assy, Blank (Single Channel)	
29	285167	Bracket (Single Channel)	
30	885088	Recorder Control Assy (See Fig. 8-6)	
31	287142	Cover (Single Channel)	



FIGURE 8-2 RECORDER SUBASSEMBLY (885287-1, -2)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
CHASSIS ASSY-SINGLE AND DUAL CHANNEL MODELS, 885111-1, 885111-2
FIGURE 8-3

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	886321	Plate Assy, R.H. Side	
2	1-128693-3	Grommet, Cat	
	686766	Motor Assy, Stepping (Includes items 3 through 5)	
3	9-281501-8	Connector	J-107
4	281502	Contact	
5	286004-1	Motor, Stepping	
6	282589	Bracket, Support	
7	240133-6	Bearing, Sleeve, Flanged	
8	682593	Pulley, Clutch Assy	
9	283864	Gear, 60 Teeth	
10	682590	Shaft, Modified	
11	270903-11	Clamp	
12	686285-1	Block Assy, R.H.	
	686285-2	Block Assy, R.H. (Dual Channel)	
13	282347-2	Spacer	
14	686278	Bar, Spacer, Top	
15	1-265849-4	Bracket, Mtg.	
16	686276	Bar, Spacer, Front	
17	886468	Harness Assy, Main (1 Req'd per channel)	
	283420-44	Connector, J201	
	286410-16	Connector, J202	
18	1-286156	Spring, Retaining	
19	232447-23	Strap, Retaining	
	686297	Track Assy, Lower (Includes items 20 through 25)	
20	285101	Clip	
21	686289	Sensor Assy	
22	285103	Clip	
23	485926	Board, P.C.	
24	281502-1	Contact, Elect.	
25	685925	Track, Lower	
26	686292	Carriage Assy (Includes items 27 through 34)	
27	686295	Lug Assy	
28	31-119914-2603	Screw, Mach, Pan Hd. Slotted	
29	686293	Carriage Subassy	
30	31-129647-40	Nut, Hex, Small Pattern	
31	1-216740-410	Lockwasher, Spring	
32	681632	Roller Assy	
33	227940-4	Ring, Retaining	
34	281630	Shaft, Eccentric, "Y" Carriage	

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
CHASSIS ASSY - SINGLE AND DUAL CHANNEL MODELS, 885111-1, 885111-2
FIGURE 8-3

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
35	686252	Contact Assy	
36	885109-1	Chassis Assy	
	885109-2	Chassis Assy (Dual Channel)	
37	686281-1	Bumper	
38	686287-1	Block Assy, L.H.	
	686287-2	Block Assy, L.H. (Dual Channel)	
39	486322	Plate, Side L.H.	
40	686277	Bar, Spacer, Rear	
41	270903-12	Clamp	
	786486	Transformer Assy, Pwr.	
42	283408	Contact, Elect.	
43	285706	Transformer	
44	9-281501-4	Connector	
45	281502	Contact, Elec.	



FIGURE 8-3 CHASSIS ASSY (885111-1, -2)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
PEN DRIVE ASSEMBLY 885112
FIGURE 8-4

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	286473	Bracket	
2	386284	Chassis, Pen Drive	
3	286307	Adapter, Shaft	
4	31-121166-2602	Screw, Set	
5	269945-23	Belt, Timing	
6	686305	Drum Assy	
7	245203-4002	Screw, Set	
8	786308-1	Bracket Assy, Pot Mtg. (Dual Channel)	
9	269945-23	Belt, Timing	
10	1-128693-3	Grommet, Cat.	
11	270903-11	Clamp	
12	1-269573-10	Spacer	
13	786315	Motor Assy, Drive	
14	286209	Clamp	
15	10-286148-103	Resistor, Variable	R-401
16	381373-3	Pulley-15 Teeth	
17	281511-1	Bearing, Ball-Flanged	
18	686311	Mount Assy, Motor	
19	269945-7	Belt, Timing	
20	286310	Shaft, Motor Drive	
21	381916-1	Pulley, 60 Teeth	
22	686312	Pulley Assy	
23	31-121166-2601	Screw, Set	
24	284431	Motor, D.C.	
25	686305	Drum Assy	
26	286307	Adapter, Shaft	
27	386309	Bracket, Pot Mtg.	
28	10-286148-103	Resistor, Variable	R-102-1
29	286209	Clamp	
30	245203-4002	Screw, Set Self Locking	
31	31-121166-2602	Screw, Set	



FIGURE 8-4 PEN DRIVE ASSEMBLY (885112)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
TABLE ASSY - 884885
FIGURE 8-5

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	684813-1	Bar, Pull	
2	285997	Spring	
3	684846	Rod Assy, Idler	
4	684843	Roller Assy, Pressure (Includes item 5)	
5	243867-11	"O" Ring	
6	784850	Plate Assy, L.H.	
7	384848	Table, Writing	
8	285200	Label, Paper Threading	
9	383798	Sprocket	
	385084	Sprocket (Metric)	
10	684842	Roller Assy, Drive	
	685174	Roller Assy, Drive (Metric)	
11	286279	Plate, Stiffener	
12	3-227070-2	Ring, Retaining	
13	284855	Roller, Idler Arm	
14	384165-4	Arm, Idler	
15	127271	Washer, Flat	
16	269945-19	Belt, Timing	
17	284814	Shaft, Support	
18	384348-3	Hub, Supply Roll	
19	283864	Gear, 60 Teeth	
20	784849	Plate Assy, R.H.	
21	0-240731-2	Ring, Retaining	
22	684847	Hub Assy, Take-Up Roll (Includes items 23 through 28)	
23	284819	Bushing, Threaded	
24	384165-2	Pulley, 28 Teeth	
25	284851-1	Disc	
26	384348-1	Hub, Take-Up Roll	
27	265672-2	Washer, Flat	
28	13-127640-5	Washer, Special	
29	2-270124-2	Nut, Lock	



FIGURE 8-5 TABLE ASSEMBLY (884885)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
RECORDER CONTROL ASSY - 885088
FIGURE 8-6

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	386039	Panel, Mtg	
2	886394	Board Assy (See Fig. 8-8 & 8-9)	
	786426	Harness Assy (Includes items 3 through 5)	
3	265760-1	Contact, Elec	
4	265840-2	Lug, Term	
5	270160-1	Lug, Term	
6	786041	Panel Subassy, Rear	
7	129758-1	Fuseholder	
8	108572-11	Strain Relief	
9	126295-7	Cord, Power	
10	241026-3	Lug, Term	
11	243898-62	Nut, Assembled Lockwasher	
12	486042	Chassis Subassy	



FIGURE 8-6 RECORDER CONTROL ASSY 885088

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
CASE ASSY - 886139
FIGURE 8-7

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	485558	Cover, Side	
	886182	Saddle Assy (Includes items 2 through 4)	
2	686096-1	Plate, Top	
3	686098	Plate, Handle Mtg.	
4	486140	Saddle	
5	686100	Plate Assy, Anchor	
6	286097	Strap, Handle	
7	685518-1	Handle	
8	2-270910-2	Bumper	



FIGURE 8-7 CASE ASSEMBLY (886139)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
RECORDER CONTROL BOARD ASSY (886394)
FIGURE 8-8

ITEM NO	PART NUMBER	DESCRIPTION
C101	240352-502	Capacitor
C102	240352-102	Capacitor
C103, C104	262585-106	Capacitor
C105	35-281295-228	Capacitor
C106	263386-108	Capacitor
C107	262585-106	Capacitor
C108	5-241145-124	Capacitor
C109	10-247116-153	Capacitor
CR103	231887	Semiconductor, Diode
CR104	246107	Semiconductor, Diode IN746
CR105	249747	Semiconductor, Diode 1N752
CR106	280440	Semiconductor, Diode 1N752
CR107, CR108	286018-1	Semiconductor, Diode 1N752
CR109	286692-1	Semiconductor
CR110 Thru CR113	231887	Semiconductor, Diode
F101, F102	116198-6	Semiconductor, Diode
J101 Thru J104	281711-16	Connector
J105-1, 2	281711-4	Connector
J107	281711-8	Connector
K101	285588	Relay
Q101	281703-2	Semiconductor, 2N4403
Q102	281702-2	Semiconductor, 2N4401
Q103	281703-2	Semiconductor, 2N4403
Q104	268925	Semiconductor, 2N4870
Q105 Thru Q112	268934-2	Semiconductor
R101	284878-503	Resistor, Variable
R102	5-241111-182	Resistor
R104	5-241111-471	Resistor
R105	5-241111-103	Resistor
R106	5-241111-124	Resistor
R107	5-241111-622	Resistor
R108	5-241111-122	Resistor
R109	5-241111-271	Resistor
R110	5-241111-223	Resistor
R111	5-241111-682	Resistor

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
RECORDER CONTROL BOARD ASSY (886394)
FIGURE 8-8

ITEM NO	PART NUMBER	DESCRIPTION
R112	5-241111-124	Resistor
R113	5-241111-182	Resistor
R114	5-241111-334	Resistor
R115	5-241111-472	Resistor
R116	5-115558-680	Resistor
R117	284878-103	Resistor, Variable
R118	5-241111-101	Resistor
R119	5-241111-103	Resistor
R122	5-241111-104	Resistor
R123	5-241111-473	Resistor
R124 Thru R127	5-115559-330	Resistor
R128	5-241111-103	Resistor
R129	5-241111-473	Resistor
R130	5-241111-681	Resistor
R131	5-241111-103	Resistor
R132	5-241111-473	Resistor
R133	5-241111-681	Resistor
R134	5-241111-103	Resistor
R135	5-241111-473	Resistor
R136	5-241111-681	Resistor
R137	5-241111-103	Resistor
R138	5-241111-473	Resistor
R139	5-241111-681	Resistor
R140	5-115558-221	Resistor
R141	5-115557-3R9	Resistor
R142	5-241111-471	Resistor
T101	286402	Transformer
T102	285775-1	Transformer
U101	230062-1	Semiconductor
U102	285589	Semiconductor 4N28
U103	286158-1	Semiconductor CMOS
U104	284684	Semiconductor CMOS
U105, U106	284681	Semiconductor CMOS



FIGURE 8-8 RECORDER CONTROL BOARD ASSEMBLY (886394)


J202
-6V
+6V
+15V
PREAMP OUTPUT
-15V
POS. SIG/COM.
COMMON
+24V
COMMON
-24V
DRIVE AMP UPPER OR LOWER CARD 286364 SCH. NO
SIGNAL CONDITIONER
USERS EVENT ACTUATION CIRCUITRY
RIGHT
LEFT
TB402
R.H. EVENT MARKER
231887
CR101
SOLENOID
HEATER
11-6222-17
OPTIONAL
L.H. EVENT MARKER
SOL.
231887
CR102
HEATER
11-6222-16
OPTIONAL
P102|J102
P103|J103
+12
+12V
-12V
END OF CHART SENSITIVITY ADJ.
R101 50K
R102 2K
R104 470
CR104 1N746
R105 10K
CR105 1N752
R109
CR103 231887
K PAPER RELAY
OPTIONAL RETRANSMITTING POT 11-6102-02
R402-2
R402-1
10K
POSITION FEEDBACK POT
OPTIONAL 2ND CHANNEL ON MODEL 15-4328-00 ONLY
FOR INTEGRATOR OPTION
TB401
PULSE INPUT
HI
COM
REMOTE START
P104|J104
J201-2
RH
W
LH
TB404
MOTOR UPPER
MOTOR LOWER
B401-2
B401-1
TB403
R401-2
R401-1
J201-1
PAPER SENSOR
U401
R140
220 1W
STRIP CHART RECORDER SINGLE CHANNEL 15-4318-00
CHART PAPER
OPTIONAL RETRANSMITTING POT 11-6102-01
LOWER
PEN HEATERS
UPPER
R 301-2
10
P101|J101
A
B
TP2
+12V
C103
10
/20
C104
10
/20
TP4
TP5
CR107 286018-1
CR108
286018-1
C105
2200
TP10
C106
1000
TP3
C107
10
/20
-12V
TRACE DENSITY
R301-1
30K
T401-1
DRIVE AMP POWER TRANS
LOWER CARD STD. CHANNEL
DRIVE AMP 286364 SCH. NO.
J201-1
T401-2
UPPER CARD OPTIONAL 2ND CHANNEL
DRIVE AMP 286364 SCH. NO.
J201-2
P105|J105 -1
P105|J105 -2
F101 .25AMP SLO BLO
F 02 .25AMP
K.01
12
13
S 102
MOTOR ON
S 101
MAIN POWER
P301
F301
SLO-BLO

REVISIONS			
SYM.	DESCRIPTION	DATE	APPROVAL
A-1	REDRAWN & REVISED PER DCN 19657 KISNER	11/25/74	
B-1	REV. PER DCN/20576	9/22/75	P.M
C-1	[illegible] DCN 20867	10/14/75	Carroll



NOTES:

1. Q105 THRU Q112 ARE 268934-2
2. SW103 SHOWN FULL CCW
3. [ ] E.I.A. COLOR CODE
4. UNLESS OTHERWISE NOTED:
   ALL CAPACITENCE IN MFD
   ALL RESISTANCE IN OHMS
   ALL RESISTORS 1/4W.
5. ARROW ON VARIABLE RESISTORS DENOTES CW DIRECTION
6. F301
   1 A FOR 115V UNITS
   .5 A FOR 230V UNITS
7. CR110 THRU 113 ARE 23887
8. P101-A CONNECTS TO J101-1 THRU-8
   P101-B CONNECTS TO J101-9 THRU-16

15-4318-16	15-4328-16
15-4318-10	15-4328-10
15-4318-06	15-4328-06
15-4318-00	15-4328-00

RECORDER ASS'Y., 10 INCH STRIP CHART

BY	DATE	NAME	
DR SNOWDEN	8/7-2	SCHEMATIC	Gould Inc. Instrument Systems Divisio Cleveland, Ohio 44114 U.S.
CH. POLLY	7/74	MODEL NO., SEE TAB.	
APP MCCAHAN	7-75	CODE IDENT. 96795	ISSUE CODE G
			DWG. NO. 286363

FIGURE 8-9 RECORDER CONTROL SCHEMATIC (28636

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
DRIVE AMPLIFIER BOARD ASSY (886046)
FIGURE 8-10

ITEM NO	PART NUMBER	DESCRIPTION
C201, C202	35-281295-228	Capacitor
C203, C204	262585-106	Capacitor
C205	240352-102	Capacitor
C206, C207	262585-106	Capacitor
C208 Thru C210	240352-102	Capacitor
C211	240352-101	Capacitor
C212	5-241145-104	Capacitor
C213	240352-101	Capacitor
C214	240352-102	Capacitor
C215	240352-101	Capacitor
C216	10-241145-103	Capacitor
C217	240352-101	Capacitor
C218, C219	240352-301	Capacitor
C220 Thru C231	262585-106	Capacitor
C232	240352-101	Capacitor
CR201	265420-1	Semiconductor, Bridge
CR202, CR203	230061-3	Semiconductor, Diode
CR204	280435-2	Semiconductor, Diode
CR205, CR206	280440	Semiconductor, Diode
CR207, CR208	244896	Semiconductor, Diode
CR209, CR210	280440	Semiconductor, Diode
CR211, CR212	269256-7	Semiconductor, Diode
Q201	2-230057-1	Semiconductor
Q202	2-230058-1	Semiconductor
Q203	242323	Semiconductor
Q204	247149	Semiconductor
Q205	242323	Semiconductor
Q206	247149	Semiconductor
Q207	283658-2	Semiconductor
Q208	268934-2	Semiconductor
Q209	2-230058-3	Semiconductor
Q210	2-230057-3	Semiconductor
R201, R202	5-115557-390	Resistor
R203, R204	5-241111-681	Resistor
R205, R206	5-115557-221	Resistor
R207	5-241111-105	Resistor
R208	5-241111-332	Resistor
R209	5-241111-472	Resistor
R210	5-241111-751	Resistor

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
DRIVE AMPLIFIER BOARD ASSY (886046)
FIGURE 8-10

ITEM NO	PART NUMBER	DESCRIPTION
R211	25-284694-53000	Resistor
R212	282299-102	Resistor, Variable
R213	25-284694-57000	Resistor
R214	25-284694-10001	Resistor
R215	282299-500	Resistor, Variable
R216, R217	25-284694-10001	Resistor
R218	25-284694-50001	Resistor
R219	25-284694-30002	Resistor
R220	282299-103	Resistor, Variable
R221	25-284694-12002	Resistor
R222	25-284694-11502	Resistor
R223	25-284694-78000	Resistor
R224	282299-502	Resistor, Variable
R225	5-241111-512	Resistor
R226	282299-103	Resistor, Variable
R227	25-265969-90001	Resistor
R228	5-241111-154	Resistor
R229	282299-103	Resistor, Variable
R230	25-265969-10003	Resistor (Single Channel Model)
	25-265969-27002	Resistor (Dual Channel Model)
R231	25-284694-96001	Resistor
R232	25-284694-90001	Resistor (Single Channel Model)
	25-284694-72001	Resistor (Dual Channel Model)
R233	5-241111-154	Resistor
R234	5-241111-303	Resistor
R235	25-265969-15001	Resistor
R236	5-241111-154	Resistor
R237	5-241111-623	Resistor
R238	5-241111-104	Resistor
R239	5-241111-103	Resistor
R240	5-241111-221	Resistor
R241	5-241111-683	Resistor
R242	5-241111-105	Resistor
R243	5-241111-243	Resistor
R244	5-241111-751	Resistor
R245	5-241111-243	Resistor
R246	5-241111-331	Resistor

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
DRIVE AMPLIFIER BOARD ASSY (886046)
FIGURE 8-10

ITEM NO	PART NUMBER	DESCRIPTION
R247	5-241111-222	Resistor
R248	5-115558-221	Resistor
R249	5-115557-331	Resistor
R250, R251	5-241111-100	Resistor
R252, R253	5-115557-120	Resistor
R254	282299-502	Resistor, Variable
U201 Thru U209	280863-3	Semiconductor



FIGURE 8-10 DRIVE AMPLIFIER BOARD ASSY (886046) (Sheet 1 of 2)



FIGURE 8-10 DRIVE AMPLIFIER BOARD ASSY (886046) (Sheet 2 of 2)



FIGURE 8-11 DRIVE AMPLIFIER SCHEMATIC (286364)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INPUT SIGNAL COUPLER 13-4715-08
FIGURE 8-12

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	285651-6	Knob, Offset Control	
2	286006-10	Post, Binding (low)	J302
3	286006-2	Post, Binding (hi)	J301
4	687555	Panel Assy	
5	243898-82	Nut, Asm. Lockwasher	
6	786040	Bracket Assy	
7	286094	Bracket, Potentiometer Mtg.	
8	10-285474-103	Resistor, Vari	R108
9	787585	Board Assy, Coupler (See Fig. 8-13)	
10	861810-364	Cable Assy	
11	247523-121	Plate, Ident.	
12	241930-3	Contact, Elec.	
13	243898-62	Nut, Asm. Lockwasher	
14	286083	Bracket, Terminal Mtg.	
15	1-216886-303	Block, Terminal	



FIGURE 8-12 INPUT SIGNAL COUPLER 13-4715-08

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INPUT SIGNAL COUPLER BOARD ASSY 787585
FIGURE 8-13

ITEM NO	PART NUMBER	DESCRIPTION
C-101	262956-226	Capacitor (22 microfarads)
C-102	262956-226	Capacitor (22 microfarads)
R-101	268940-502	Resistor, Vari ("Trim" Pot)
R-102	25-265969-75000	Resistor (7.5K)
R-103	25-265969-30001	Resistor (30K)
R-104	25-265969-50001	Resistor (50K)
R-105	25-265969-10002	Resistor (100K)
R-106	25-265969-50001	Resistor (300K)
R-107	25-265969-50002	Resistor (50K)



FIGURE 8-13 INPUT SIGNAL COUPLER BOARD ASSY (787585)



NOTES

1. UNLESS OTHERWISE NOTED:
   ALL CAPACITANCE IN MICROFARADS.
   ALL RESISTANCE IN OHMS.
   ALL RESISTORS 1/4 WATT.
   ALL RESISTORS WITH SUFFIX C = .25%.
2. ARROW ON VARIABLE RESISTORS INDICATES CW DIRECTION.
3. CHASSIS
   CIRCUIT COMMON

REVISIONS			
DASH	DESCRIPTION	DATE	APPROVAL
A-1	REV WIRING, R101 DCN 20277	7-9-75	P MILLER

INPUT COUPLER

E MILLER 7/75	SCHEMATIC	Gould Inc. Instruments Systems Division Cleveland, Ohio 44114 U.S.A.
	MODEL NO 13-87-5-06	287302
	96795 CODE	6

FIGURE 8-14 INPUT SIGNAL COUPLER SCHEMATIC (287302)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
FIXED SPAN DC AMPLIFIER (13-4715-07)
FIGURE 8-15

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	285651-6	Knob, Control	
2	286006-6	Post, Binding	J303
3	286006-10	Post, Binding	J302
4	286006-2	Post, Binding	J301
5	11-4601-XX	Plug in Fixed Gain (16 Available)	
6	686043	Panel Assy	
7	786040	Bracket Assy	
8	243898-82	Nut Assy	
9	286094	Bracket Mtg, Pot	
10	10-285474-103	Resistor, Var.	R106
11	886021	Board Assy, Amp (See Figure 8-16)	
12	———	Not Used	
13	270903-6	Clamp	
14	861810-364	Cable Assy	
15	243898-62	Nut Assy	
16	286083	Bracket Mtg.	
17	1-216886-303	Block, Terminal	
18	247523-97	Plate, Ident.	



FIGURE 8-15 FIXED SPAN DC AMPLIFIER (13-4715-07)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
FIXED SPAN AMPLIFIER BOARD ASSY (886021)
FIGURE 8-16

ITEM NO	PART NUMBER	DESCRIPTION
C102, C103	231922-107	Capacitor
C104	10-241145-325	Capacitor
C105, C106	262956-226	Capacitor
CR101, CR102	281845-6	Semiconductor, Diode
J101	285940-8	Connector
R101	5-285473-50000	Resistor
R102	5-241111-105	Resistor
R103	5-241111-103	Resistor
R104	282299-503	Resistor, Variable
R105	5-241111-104	Resistor
R107, R108	5-241111-101	Resistor
U101	284877	Semiconductor, I.C.



FIGURE 8-16 FIXED SPAN AMPLIFIER BOARD ASSY (886021)



FIGURE 8-17 FIXED SPAN AMPLIFIER SCHEMATIC (286362)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
MULTI-SPAN AMPLIFIER ASSY (13-4715-06)
FIGURE 8-18

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	286006-6	Post, Binding (Blue)	J203
2	286006-10	Post, Binding (Black)	J202
3	286006-2	Post, Binding (Red)	J201
4	284990	Knob, Turns Counterclockwise	
5	285650	Knob, Control	
6	285651-2	Knob, Control	
7	285653-1	Knob, Control	
8	684931	Panel Assy	
9	786040	Bracket, Assy	
10	269094-103	Resistor, Variable	R201
11	861810-364	Cable Assy	
12	885981	Board Assy, Amp (See Figure 8-19)	
13	247523-96	Plate, Ident	
14	243898-62	Nut Assy	
15	286083	Bracket, Term, Mtg	
16	1-216886-303	Block, Term	
17	268921	Switch, Toggle	S201



FIGURE 8-18 MULTI SPAN AMPLIFIER ASSY (13-4715-06)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
MULTI-SPAN AMPLIFIER BOARD ASSY (885981)
FIGURE 8-19

ITEM NO	PART NUMBER	DESCRIPTION
C101	5-241145-204	Capacitor
C102, C103	269255-107	Capacitor
C104	5-241145-105	Capacitor
C105	5-241145-254	Capacitor
C106, C107	5-241145-203	Capacitor
C108	5-241145-645	Capacitor
C109	5-241145-295	Capacitor
C110	5-241145-195	Capacitor
C111	5-241145-144	Capacitor
C112	240352-202	Capacitor
C113	5-241145-485	Capacitor
C114	5-241145-225	Capacitor
C115	5-241145-155	Capacitor
C116	5-241145-104	Capacitor
C118, C119	262956-226	Capacitor
CR101, CR102	281845-6	Semiconductor, Diode
R101	5-284693-99502	Resistor
R102	5-285473-50000	Resistor
R103	5-285473-50000	Resistor
R104	5-284693-50000	Resistor
R105, R106	5-241111-101	Resistor
R107	282299-502	Resistor, Variable
R108	282299-503	Resistor, Variable
R109	25-265969-50001	Resistor
R110	285541	Switch
R111	5-284693-80001	Resistor
R112	5-284693-10001	Resistor
R113	5-284693-50000	Resistor
R114	5-284693-30000	Resistor
R115	5-284693-30000	Resistor
R116	5-284693-500R0	Resistor
R117	5-284693-300R0	Resistor
R118	5-284693-100R0	Resistor
R119	5-284693-50R00	Resistor
R120	R05-246659-30R00	Resistor
R121, R122	R05-246659-10R00	Resistor
R123	25-265969-10001	Resistor
R124	25-265969-40001	Resistor

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
MULTI-SPAN AMPLIFIER BOARD ASSY (885981)
FIGURE 8-19

ITEM NO	PART NUMBER	DESCRIPTION
R125	25-265969-50001	Resistor
R126	5-241111-104	Resistor
R127, R128	R1-284694-10001	Resistor
R129	5-241111-512	Resistor
R130	R1-284694-40000	Resistor
R131	R1-284694-60360	Resistor
R132	R1-284694-10003	Resistor
R133, R134	R1-284694-83302	Resistor
R135	282299-204	Resistor, Variable
R136	R1-284694-90002	Resistor
R137, R138	R1-284694-83302	Resistor
S101	285541	Switch
S102	285520	Switch
U101	284877	Amplifier
U102	281101	Semiconductor, Amplifier
U103	28086B-1	Semiconductor, Amplifier
U104	230062	Semiconductor, Amplifier



FIGURE 8-19 MULTI SPAN AMPLIFIER BOARD ASSY (885981) (Sheet 1 of 2)



FIGURE 8-19 MULTI SPAN AMPLIFIER BOARD ASSY (885981) (Sheet 2 of 2)


FRONT PANEL
FINE BALANCE
R107
COARSE BALANCE
R108
OFFSET ADJ
R135
-15V
+15V
E
C
R105
100
J
R106
100
J
C102
100
C103
100
R107
5K
R108
50K
FINE BALANCE
COARSE BALANCE
R109
50K-C
VOLTS
VAR. GAIN
R110
200K
R111
80K
VOLTS
H
G
COM
F
J202
VOLTS/MV
S102-B
VOLTS
MV
MV
VOLTS
U101*
284877
R112
10K
SPAN
S101
OFF
J301
HI
[2]
J302
LOW
[0]
J303
GD
SHIELD
R101
995K
R102
5K-J
2W
R103
5K-J
2W
C101
.2
CR101
281845-6
CR102
281845-6
VOLTS
MV
R104
5K
TB101
1
2
3
[2]
[0]
SHIELD
100
50
20
10
5
2
1
.5
.2
.1
C104
1.0
C105
.25
C106
.02
C107
.02
R113
5K
R114
3K
R115
1K
R116
500
R117
300
R118
100
R119
50
R120
30
R121
10
R122
10

REVISIONS			
SYM.	DESCRIPTION	DATE	APPROVAL
A-1	U104 WAS: 301 DCN 20464	8/22/75	
B-		11/15/75	P. M.



TOP VIEW (284877)

TOP VIEW
COMPENSATION (301 ONLY)

(281101, 741, 301)

NOTES

1. UNLESS OTHERWISE INDICATED
   ALL CAPACITANCE IN MICROFARADS
   ALL RESISTANCE IN OHMS
   ALL VOLTAGES REFERENCED TO CIRCUIT COMMON
2. ALL RESISTORS WITH SUFFIX
   B=.1%-1/4W
   C=.25%-1/4W
   J= 5%-1/2W
3. ALL UNMARKED RESISTORS ARE .05% 1/2W.
4. ARROW ON VARIABLE RESISTORS & SWITCHES DENOTES CW ROTATION.
5. CHASSIS
   GUARD SHIELD
   CIRCUIT COMMON

VARIABLE GAIN AMPLIFIER

BY	DATE	NAME	Gould Inc. Instrument Systems Division Cleveland, Ohio 44114 U.S.A.
DR SNOWDEN	6/74	SCHEMATIC MODEL NO. 13-4715-06	
CH.		CODE IDENT. 96795	ISSUE CODE G
APP.			DWG. NO. 286361

FIGURE 8-20 MULTI SPAN AMPLIFIER SCHEMATIC (286361)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
LIMIT SWITCH ASSY OPTION (SINGLE CHANNEL 11-6103-01) (DUAL CHANNEL 11-6103-02)
FIGURE 8-21

ITEM NO	PART NUMBER	DESCRIPTION
1	287007	Label, Limit Controls
2	385108	Panel, Limit Controls
3	263451-4	Guide, P.C. Board
4	1-286155-6	Board, Terminal
		(Attaching Parts)
	31-119918-6210	Screw, Pan
	1-216741-420	Lockwasher, Spring
	31-119998-62	Nut, Hex
5	886705	Board Assy, Limiter (Single Channel) } See Fig.8-22
	886707	Board Assy, Limiter (Dual Channel) }
6	286756	Bracket, Cable
7	9-281501-15	Connector
8	281502	Contact, Elect.
9	1-283408-1	Contact
10	265915-1	Contact
11	385110	Panel, Fill



FIGURE 8-21 LIMIT SWITCH ASSY (11-6103-01, 02)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
LIMIT SWITCH BOARD ASSY (SINGLE CHANNEL 886705)
FIGURE 8-22 (Sheet 1 of 3)

ITEM NO	PART NUMBER	DESCRIPTION
C101, C102	240352-103	Capacitor
C103, C104	240352-300	Capacitor
CR101, CR102	280440	Semiconductor, 1N4148
CR103, CR104	231887	Semiconductor, SI-1
CR105, CR106	285578	Semiconductor, LED
K101, K102	285771-24	Relay
P101	281711-15	Connector
Q101	268934-2	Semiconductor, MPS 6531
Q102	283658-2	Semiconductor, MPS 6534
R101, R104	5-241111-223	Resistor
R102, R103	20-285471-104	Resistor, Vari.
R105, R106	5-241111-104	Resistor
R107 Thru R110	5-241111-333	Resistor
R111, R112	5-241111-156	Resistor
R113, R114	5-241111-752	Resistor
R115, R116	5-241111-101	Resistor



FIGURE 8-22 LIMIT SWITCH BOARD ASSY (SINGLE CHANNEL 886705)
(Sheet 1 of 3)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
LIMIT SWITCH BOARD ASSY (DUAL CHANNEL 886707)
FIGURE 8-22 (Sheets 2 & 3 of 3)

ITEM NO	PART NUMBER	DESCRIPTION
C101, C102 C105, C106	240352-103	Capacitor
C103, C104 C107, C108	240352-300	Capacitor
CR101, CR102 CR107, CR108	280440	Semiconductor, 1N4148
CR103, CR104 CR109, CR110	130198-1	Semiconductor, SI-1
CR105, CR106 CR111, CR112	285578	Semiconductor, LED
K101 Thru K104	285771-24	Relay
P101, P102	281711-15	Connector
Q101, Q103	268934-2	Semiconductor, MPS 6531
Q102, Q104	283658-2	Semiconductor, MPS 6534
R101, R104 R117, R120	5-241111-223	Resistor
R102, R103 R118, R119	20-285471-104	Resistor, Vari.
R105, R106 R121, R122	5-241111-104	Resistor
R107 thru R110 R123 thru R126	5-241111-333	Resistor
R111, R112 R127, R128	5-241111-156	Resistor
R113, R114 R129, R130	5-241111-752	Resistor
R115, R116 R131, R132	5-241111-101	Resistor
U101 Thru U104	230062-1	Semiconductor, LM 301



FIGURE 8-22 LIMIT SWITCH BOARD ASSY (DUAL CHANNEL 886707)
(Sheet 2 of 3)



FIGURE 8-22 LIMIT SWITCH BOARD ASSY (DUAL CHANNEL 886707)
(Sheet 3 of 3)



FIGURE 8-23 LIMIT SWITCH SCHEMATIC (286368)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INTEGRATOR PEN OPTION (SINGLE CHANNEL 11-6105-00) (DUAL CHANNEL 11-6105-01)
FIGURE 8-24 (Sheet 1 of 2)

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
1	786282	Scale Assy S.S.	
2	11-2874-33	Stylus Assy	
3	686281-2	Bumper	
		Harness Assy	
4	9-281501-15	Connector	J-101
5	281502	Contact	
6	265760-1	Contact	
7	9-281501-10	Connector	J-201
8	262852	Switch	S-101
9	230064-103	Resistor, Variable	R-403
10	1-283408-1	Contact	
11	280757	Connector	J-301
12	4-281501-6	Connector	J-104
13	286768	Pulley	
14	281585	Cable	
15	386649	Sector, Integrator	
16	682145	Drive Band Assy	
17	31-241908-2602	Screw, Cap, Skt, Hd.	
18	281396	Washer, Band	
19	782236	Arm Assy Drive	
20	267598	Bearing, Ball	
21	286645	Gear, Pinion	
22	31-121166-2602	Screw, Set	
23	2-269579-2	Spacer	
24	786650	Bearing, Retainer Mod	
25	243225-3	Clamp, Cable	
26	386647	Plate, Mtg	
27	286655	Clamp, Motor	
28	286653	Clamp, Pot	
29	50-286149-103	Pot, Feedback	
30	265827-4	Spacer	
31	281622-1	Shaft	
32	286651	Plate, Bearing	
33	230066	Washer, Spacer	
34	9-227070-6	Ring, Retainer	
35	285583	Motor, Drive	

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INTEGRATOR PEN OPTION (SINGLE CHANNEL 11-6105-00) (DUAL CHANNEL 11-6105-01)
FIGURE 8-24 (Sheet 2 of 2)

ITEM NO	PART NUMBER	DESCRIPTION	SYMBOL NO
36	385110	Panel, Fill	
37	285651-4	Knob	
38	385108	Panel, Limit Controls	
39	286666	Label	
40	886046-2	Board Assy, Drive Amp (See Fig. 8-10)	
41	263451-4	Guide, P.C. Board	
42	886663	Board Assy, Integrator (See Fig 8-25 & 8-27)	
43	265849-4	Bracket	
44	267235	Jumper	
45	786661	Power Supply (See Fig. 8-26 & 8-27)	
46	124804-4	Clamp, Cable	



FIGURE 8-24 INTEGRATOR PEN OPTION (SINGLE AND DUAL CHANNEL 11-6105-00, -01)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INTEGRATOR BOARD ASSY 886663
FIGURE 8-25

ITEM NO	PART NUMBER	DESCRIPTION
C101	230098-104	Capacitor
C102	10-287730-106	Capacitor
C103	10-241145-504	Capacitor
C104	281344-103	Capacitor
C105	232920-336	Capacitor
C106	10-241145-474	Capacitor
C107	10-241145-105	Capacitor
C108	263343-156	Capacitor
C109	10-241145-404	Capacitor
C110	263343-156	Capacitor
C111	10-241145-404	Capacitor
CR101, CR102	263727	Semiconductor, Diode 1N961B
CR103	280440	Semiconductor, Diode 1N4148
P101	281711-15	Connector
Q101	230057-1	Semiconductor Transistor 2N4921
Q102	230058-1	Semiconductor Transistor 2N4918
R101, R102	25-284694-10002	Resistor
R103	25-265969-10000	Resistor
R104	25-284694-10002	Resistor
R105	25-284694-20002	Resistor
R106	269085-503	Resistor, Variable
R107	R1-284694-10001	Resistor
R108	25-284694-85000	Resistor
R109	269085-202	Resistor, Variable
R110, R111	25-284694-10002	Resistor
R112	269085-104	Resistor, Variable
R113	25-265969-10000	Resistor
R114	5-241111-392	Resistor
R115	R1-284694-10001	Resistor
R116	R1-284694-25000	Resistor
R117, R118	5-241111-242	Resistor
R119	R1-284694-10001	Resistor
R120	R1-284694-25000	Resistor
R121	5-241111-393	Resistor
R122	R1-284694-10001	Resistor
R123	R1-284694-75000	Resistor
R124	R1-284694-25000	Resistor
R125, R126	5-241111-472	Resistor
R127	R1-284694-25000	Resistor
R128	R1-284694-75000	Resistor

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INTEGRATOR BOARD ASSY 886663
FIGURE 8-25

ITEM NO	PART NUMBER	DESCRIPTION
R129	R1-284694-10001	Resistor
R130	1-265969-40000	Resistor
R131	25-265969-80000	Resistor
R132	25-265969-40001	Resistor
R133	25-265969-8000	Resistor
R134	282299-503	Resistor, Variable
R135	25-265969-33001	Resistor
R136	25-265969-10001	Resistor
R137, R138	25-284694-10002	Resistor
R139, R140	25-284694-50001	Resistor
R141	5-241111-682	Resistor
R142	25-265969-58001	Resistor
R143	282299-202	Resistor, Variable
R144	25-265969-10003	Resistor
R145, R146	5-246857-220	Resistor
R147	25-284694-50000	Resistor
R149	282299-502	Resistor, Variable
R150	25-265969-15001	Resistor
R153, R154	25-284694-10002	Resistor
R155	269085-103	Resistor, Variable
R156	25-265969-12000	Resistor
R157	R1-284694-25000	Resistor
R158	25-284694-50000	Resistor
R159	5-241111-472	Resistor
R160	R1-284694-25000	Resistor
R161	R1-284694-10001	Resistor
R162	5-241111-472	Resistor
R163	R1-284694-10001	Resistor
R164	25-265969-10001	Resistor
S101	247431	Switch, Slide, SPDT
U101, U102	287740	Integrated Circuit, CA324E
U103, U104	287602	Integrated Circuit, MPQ6700
U105	270622	Integrated Circuit, SN7493AN
U106	287498	Integrated Circuit, MC7812
U107	287496	Integrated Circuit, MC7912
U108	281115-1	Integrated Circuit, LM309



FIGURE 8-25 INTEGRATOR BOARD ASSY 886663 (Sheet 1 of 2)



FIGURE 8-25 INTEGRATOR BOARD ASSY 886663 (Sheet 2 of 2)

EXPLODED VIEW PARTS LIST
GOULD 110 RECORDER
INTEGRATOR POWER SUPPLY BOARD ASSY 786661
FIGURE 8-26

ITEM NO	PART NUMBER	DESCRIPTION
C201, C202	281509-507	Capacitor
CR201	286018-1	Diode Assy
F201	116198-4	Fuse
K201	262185	Relay
P201	281711-10	Connector
T201	285596	Transformer



FIGURE 8-26 INTEGRATOR POWER SUPPLY BOARD ASSY 786661



NOTES:

1. UNLESS OTHERWISE INDICATED:
   ALL CAPACITANCE IN MICROFARADS.
   ALL RESISTANCE IN OHMS.
   ALL VOLTAGES REFERENCED TO CIRCUIT COMMON.
2. RESISTOR TOLERANCES:
   B = .1%, 1/4 W
   J = 5% 1/4 W
3. ARROWS ON VARIABLE RESISTORS & SWITCHES DENOTES CW ROTATION.
4. ⏚ DENOTES COMMON FROM DRIVE AMP.
5. R151 ON SUBPANEL BEHIND SUPPLY ROLLS.
6. S202 ON SUBPANEL NEXT TO R151.

RECORDER CONTROL ASSY. 886394

PEN HEATER

PEN 111-2874-33



FIGURE 8-27 INTEGRATOR PEN SCHEMATIC (286366)

PICTORIAL VIEW PARTS LIST
GOULD 110 RECORDER
RETRANSMITTING POTENTIOMETER ASSY – SINGLE CHANNEL (11-6102-01)
FIGURE 8-28

ITEM NO	PART NUMBER	DESCRIPTION
1	885112-3	Pen Drive Assy
2	686495	Harness Assy
3	1-286155-4	Board, Terminal
4	31-119918-6210	Screw, Pan Hd.
5	1-216741-420	Lockwasher, Spring
6	31-119998-62	Nut, Hex



FIGURE 8-28 RETRANSMITTING POTENTIOMETER ASSY - SINGLE CHANNEL (11-6102-01)

PICTORIAL VIEW PARTS LIST
GOULD 110 RECORDER
RETRANSMITTING POTENTIOMETER ASSY - DUAL CHANNEL (11-6102-02)
FIGURE 8-29

ITEM NO	PART NUMBER	DESCRIPTION
1	786308-2	Bracket Assy., Pot Mtg. (Replacement for 786308-1)
2	686495	Harness Assy
3	1-286155-4	Board, Terminal
4	31-119918-6210	Screw, Pan Hd.
5	1-216741-420	Lockwasher, Spring
6	31-119998-62	Nut, Hex



FIGURE 8-29 RETRANSMITTING POTENTIOMETER ASSY – DUAL CHANNEL (11-6102-02)

www.manualsplus.com
1026016

Gould Inc., Instrument Systems Division
3631 Perkins Avenue, Cleveland, Ohio 44114
Telephone (216) 361-3315

GOULD